

# DOUBLE HAMMOCK STAND

914920, 914921, 914922

**MAX Capacity: 550 lbs**

**Dimensions: 9 ft. X 3 ft.**

## HARDWARE

- ① Hook, Wingnut, & Washer Set (2)      ② Knob Screw (5)

## PARTS

- Ⓐ Base (2)      Ⓑ Cross Bar      Ⓒ Hammock Frame Bar (2)      Ⓓ Carrying Bag  
Ⓔ Double Hammock

Download **BONUS**  
Relaxation mp3



<http://bit.ly/Hammock-user-guide>

## IMPORTANT:

- Firmly secure all screws before use.
- Product is intended for outdoor use.
- If any parts are missing, broken, damaged, or worn, *stop* using this item until repairs are made and/or factory replacement parts are installed.
- Do not use this item in a way inconsistent with manufacturer's instructions as this could void the product warranty.

## CAUTION: **MAX Capacity: 550 lbs**

- Ensure hammock stand is on level ground for proper balance.
- Do *not* leave children unattended while on hammock.
- Do *not* use hammock or stand as a swing.
- Always enter hammock from middle.
- Do *not* sit past base legs of hammock stand.
- Ensure the hook and wingnuts are secured on a regular basis.
- Inspect hammock and frame for signs of deterioration or damage frequently. Do *not* use this product if worn or damaged.



## IMPORTANT:

Install hook on the side that is facing away from hammock. See the close up image of hardware #1.

Please help us provide the best service we possibly can, by emailing your parts and service needs to

[ddiparts@ddicorp.com](mailto:ddiparts@ddicorp.com)

914920 914921 914922