

915002-WB FIRE PIT

Assembly Instructions

Please check the carton and packing materials before disposing to make sure that you have all the parts for this product.

Part List

Part List	Description	Qty.	Drawings
A	Fire Bowl	1	
B	Outer Ring	4	
C	Leg	3	
D	Log Grate	1	
E	Mesh Lid	1	
F	Lid Ring	1	
G	Bolt	18	
H	Connector A	4	
I	Connector B	4	
J	Poker	1	
K	Allen Wrench	1	

Assembly Instructions

Please check all packing material carefully before discarding, as some parts may be encased in the packing material.

Step 1 Attach the Legs (C) to the Fire Bowl (A) by using bolts (G). Finger Tighten and do not fully tighten all bolts.



Step 2 Attach Connect B (I) to the Fire Bowl (A) by using bolts (G). Connect 4PCS of Outer Ring (B) to a round ring. Hold the fixed round ring by Connector A (H) and Connector B (I) by using Bolts (G) . Tighten all the bolts accordingly with the provided Allen Wrench until all pieces fit together securely Put Log grate (D) into the Fire Bowl (A) .



Step 3 Place BBQ grill (E) onto the Support Bar (I). Affix Lid Ring (F) to the Mesh Lid (E) by screwing the lid ring into the upper hole of the mesh lid. Then place the mesh lid on the Fire Bowl (A).



Your Fire Pit is ready for use now!



BACKYARD *expressions*
PATIO • HOME • GARDEN

Customers and Stores - Please help us give you the best possible service by emailing your parts and service needs to: **customerservice@ddicorp.com**

Emails are responded to quickly and are the fastest and most accurate way to communicate item/parts needs.

PLEASE KEEP ORIGINAL RECEIPT AND INSTRUCTION MANUAL for possible future reference. **Original receipt is required for any warranty claims**

In addition to your purchase receipt please include the following information in your email:

Item Name	4pc Seating Chair sets-Textline
Item Code /UPC Code (Begins with 6-81129-)	915002 /6 8112915002
Specific Issue	
Part Needed—Please Identify from Assembly Instructions	
Your Shipping Address	

Parts and parts listings for many of our products can be found at:
<https://backyard-expressions.com/collections/replacement-parts>

PRODUCT WARRANTY SHALL NOT APPLY TO ANY PRODUCT OR ANY PART THEREOF, WHICH HAS BEEN SUBJECT TO ACCIDENT, NEGLIGENCE, WEATHER RELATED DAMAGE, ALTERATION, ABUSE, OR MISUSE OR TO PRODUCT SOLD AS-IS, END OF SEASON, OPEN BOX OR OTHER SUBSTANTIALLY DISCOUNTED PRODUCT. DDI MAKES NO WARRANTY WHATSOEVER IN RESPECT TO ACCESSORIES OR PARTS NOT SUPPLIED BY US.

DDI IS NOT RESPONSIBLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES, WHICH MAY ARISE OUT OF THE PURCHASE OR USE OF ANY DDI PRODUCT. PRODUCT LIABILITY FOR ANY BREACH OF THIS WARRANTY SHALL BE AT THE DISCRETION OF DDI AND LIMITED TO REPAIR OR REPLACEMENT OF THE DEFECTIVE PRODUCT.

WARRANTY CLAIMS RECEIVED 90 DAYS AFTER PURCHASE DATE (RECEIPT REQUIRED) MAY BE SUBJECT TO ADDITIONAL COSTS AND ARE ASSESSED BY THE WARRANTY CLAIM DEPARTMENT.

If you prefer you may also leave a message or send a text to **1-612-888-7550**
Your message will be responded to during normal weekday business hours in the order received.