



Small frame,
Vision TFE PRO extensions

STACK @ top of armrest (cm)	desired STACK (cm)	pedestal stack (mm)
	65.0	125
	64.5	120
	64.0	115
	63.5	110
	63.0	105
	62.5	100
	62.0	95
	61.5	90
	61.0	85
	60.5	80
	60.0	75
	59.5	70
	59.0	65
	58.5	60
	58.0	55
57.5	50	
57.0	45	
56.5	40	
56.0	35	
55.5	30	

frame stack	47.5
-------------	------

REACH @ armrest (cm)	REACH @ back of armrest	REACH @ middle of armrest	bracket position	hole position on bridge (back to front)	hole position on armrest (always row 2)
	48.3	54.3	forward	row 7+	row 2
	47.5	53.5	forward	row 7	row 2
	46.8	52.8	forward	row 6	row 2
	46.0	52.0	forward	row 5	row 2
	45.3	51.3	forward	row 4	row 2
	44.5	50.5	forward	row 3	row 2
	43.8	49.8	forward	row 2	row 2
	43.0	49.0	forward	row 1	row 2
	43.0	49.0	rearward	row 7+	row 2
	42.3	48.3	rearward	row 7	row 2
	41.5	47.5	rearward	row 6	row 2
	40.8	46.8	rearward	row 5	row 2
	40.0	46.0	rearward	row 4	row 2
	39.3	45.3	rearward	row 3	row 2
	38.5	44.5	rearward	row 2	row 2
37.8	43.8	rearward	row 1	row 2	
frame reach	39.5				

REACH @ shifter (cm)	Length of TFE Pro Aero Extension			
	Small 26.5	Medium 28.5	Large 30.5	X-Large 32.5
	79.3	81.3	83.3	85.3
68.8	70.8	72.8	74.8	

WIDTH @ armrest (cm)	WIDTH @ outside of armrest	WIDTH @ inside of armrest	hole position on bridge (left to right)	hole position on armrest (left to right)
	30.6	20.6	column 3	column 4
	29.1	19.1	column 2	column 3
	27.6	17.6	column 3	column 4
	26.1	16.1	column 2	column 3
	24.6	14.6	column 3	column 3
	23.1	13.1	column 2	column 2
	21.6	11.6	column 1	column 1
	20.1	10.1	column 2	column 1



Medium frame,
Vision TFE PRO extensions

STACK @ top of armrest (cm)	desired STACK (cm)	pedestal stack (mm)
	67.0	125
	66.5	120
	66.0	115
	65.5	110
	65.0	105
	64.5	100
	64.0	95
	63.5	90
	63.0	85
	62.5	80
	62.0	75
	61.5	70
	61.0	65
	60.5	60
	60.0	55
59.5	50	
59.0	45	
58.5	40	
58.0	35	
57.5	30	

frame stack	49.5
-------------	------

REACH @ armrest (cm)	REACH @ back of armrest	REACH @ middle of armrest	bracket position	hole position on bridge (back to front)	hole position on armrest (always row 2)
	50.8	56.8	forward	row 7+	row 2
	50.0	56.0	forward	row 7	row 2
	49.3	55.3	forward	row 6	row 2
	48.5	54.5	forward	row 5	row 2
	47.8	53.8	forward	row 4	row 2
	47.0	53.0	forward	row 3	row 2
	46.3	52.3	forward	row 2	row 2
	45.5	51.5	forward	row 1	row 2
	45.5	51.5	rearward	row 7+	row 2
	44.8	50.8	rearward	row 7	row 2
	44.0	50.0	rearward	row 6	row 2
	43.3	49.3	rearward	row 5	row 2
	42.5	48.5	rearward	row 4	row 2
	41.8	47.8	rearward	row 3	row 2
	41.0	47.0	rearward	row 2	row 2
40.3	46.3	rearward	row 1	row 2	
frame reach	42.0				

REACH @ shifter (cm)	Length of TFE Pro Aero Extension			
	Small 26.5	Medium 28.5	Large 30.5	X-Large 32.5
	81.8	83.8	85.8	87.8
71.3	73.3	75.3	77.3	

WIDTH @ armrest (cm)	WIDTH @ outside of armrest	WIDTH @ inside of armrest	hole position on bridge (left to right)	hole position on armrest (left to right)
	30.6	20.6	column 3	column 4
	29.1	19.1	column 2	column 3
	27.6	17.6	column 3	column 4
	26.1	16.1	column 2	column 3
	24.6	14.6	column 3	column 3
	23.1	13.1	column 2	column 2
	21.6	11.6	column 1	column 1
	20.1	10.1	column 2	column 1



Large frame,
Vision TFE PRO extensions

STACK @ top of armrest (cm)	desired STACK (cm)	pedestal stack (mm)
	71.0	125
	70.5	120
	70.0	115
	69.5	110
	69.0	105
	68.5	100
	68.0	95
	67.5	90
	67.0	85
	66.5	80
	66.0	75
	65.5	70
	65.0	65
	64.5	60
64.0	55	
63.5	50	
63.0	45	
62.5	40	
62.0	35	
61.5	30	

frame stack	53.5
-------------	------

REACH @ armrest (cm)	REACH @ back of armrest	REACH @ middle of armrest	bracket position	hole position on bridge (back to front)	hole position on armrest (always row 2)
	53.1	59.1	forward	row 7+	row 2
	52.3	58.3	forward	row 7	row 2
	51.6	57.6	forward	row 6	row 2
	50.8	56.8	forward	row 5	row 2
	50.1	56.1	forward	row 4	row 2
	49.3	55.3	forward	row 3	row 2
	48.6	54.6	forward	row 2	row 2
	47.8	53.8	forward	row 1	row 2
	47.8	53.8	rearward	row 7+	row 2
	47.1	53.1	rearward	row 7	row 2
	46.3	52.3	rearward	row 6	row 2
	45.6	51.6	rearward	row 5	row 2
	44.8	50.8	rearward	row 4	row 2
	44.1	50.1	rearward	row 3	row 2
43.3	49.3	rearward	row 2	row 2	
42.6	48.6	rearward	row 1	row 2	
frame reach	44.3				

REACH @ shifter (cm)	Length of TFE Pro Aero Extension			
	Small 26.5	Medium 28.5	Large 30.5	X-Large 32.5
	84.1	86.1	88.1	90.1
73.6	75.6	77.6	79.6	

WIDTH @ armrest (cm)	WIDTH @ outside of armrest	WIDTH @ inside of armrest	hole position on bridge (left to right)	hole position on armrest (left to right)
	30.6	20.6	column 3	column 4
	29.1	19.1	column 2	column 3
	27.6	17.6	column 3	column 4
	26.1	16.1	column 2	column 3
	24.6	14.6	column 3	column 3
	23.1	13.1	column 2	column 2
	21.6	11.6	column 1	column 1
	20.1	10.1	column 2	column 1