

DISPLAY **A**

Watch hands

60 seconds counter

30 minutes counter

1/10 second counter

Pushbutton A

Pushbutton B

Hour hand

Sekund hand

Date-indicator

Minute hand

Setting crown (position I, II, III)

SETTING THE COUNTERS TO ZERO **B**

Setting crown in position II

Selecting the counter for zero-reset. (The selected hand moves).

1

Setting crown

2

Zero-setting the selected hand.

SETTINGS **C**

Setting crown 3 positions

Normal running of watch

Rapide correction of the date

Correction time position: stop second and correction of the date at every passing to midnight

Note
Setting crown in position III: **STOP-SECOND**

TIMING MODE **D**

Simple timing function

START 1

STOP 2

Read time
- 5 minutes
- 57 seconds
- 7/10 second

Reset to zero 3

Setting crown in position I

1 to 3 order of functions

WARNING
Before starting the time, put back the chronograph hands to their original position. If necessary, see paragraph **SETTING THE TIMERS TO ZERO**



WWW.RUFWATCHES.COM

ETA G10.212 AB PWD

633 497 - 31.07.2015 / ETA / 00

TIMING MODE **E**

ADD function

1 START

Setting crown in position I

X Reset to zero after a STOP

2 STOP Read

3 RESTART

4 STOP Read

5 RESTART

6 STOP Read

1 to X order of functions

TIMING MODE **F**

SPLIT-TIME or INTERMEDIATE TIMES function

START 1

Setting crown in position I

SPLIT 1 2

Read time 1
- 5 minutes
- 4 seconds
- 6/10 second

RESTART 3 (catching-up)

SPLIT 2 4

Read time 2
- 15 minutes
- 36 seconds
- 8/10 second

RESTART 5 (catching-up)

STOP 6

Read LAST TIME
- 25 minutes
- 18 seconds
- 4/10 second

Reset to zero 7

1 to 7 order of functions