

NEO 2

Portable Speaker

Quick Start Guide


Important safety instructions

Please read these instructions and then keep them safe for future reference.

1. Heed all warnings and follow all instructions in this manual.
2. Do not use this product near water, or where it may become wet.
3. Only clean this product with a dry, lint-free cloth.
4. Do not block any vents, and only install in accordance with the manufacturer's instructions.
5. Do not use this product near to any heat sources such as radiators, heaters, cookers or other devices (including amplifiers) that produce heat.
6. Protect all cables from damage by avoiding sharp objects, bending around tight corners, and from friction or crushing damage caused for example by walking on them.
7. Use only attachments or accessories as specified by the manufacturer.
8. Unplug this product during lightning storms or in prolonged periods of disuse.
9. Refer all servicing to qualified persons. Servicing may be required when the product has been damaged in any way, does not operate normally or has been dropped.
10. Do not install this product in a confined or built-in space such as a bookcase or similar unit.
11. **WARNING:** Please refer to the information on the safety labels on the product or its power supply before installing or operating the device.
12. **WARNING:** To reduce the risk of fire or electrical shock, do not expose this product to rain or moisture. The product should not be exposed to dripping or splashing and objects filled with liquids should not be placed on the product.
13. **CAUTION:** This product contains a Lithium battery. Incorrect disposal of this battery may result in explosion.
14. The recommended operating temperature range for this product is 5-40°C Celsius

Recycling


This product CAN be recycled. Products bearing this symbol  must NOT be thrown away with normal household waste. At the end of the products life, take it to a collection point designated for recycling of electronic devices. Find out more about return and collection points through your local authority.



1. Controls
2. Digital Display
3. Aux Input
4. USB Drive Input

5. Mic Volume
6. Power On/Off
7. Mic Input
8. Charging Port

9. micro SD Input
10. Charging LED
11. Music Volume



Controls

1. Previous
2. Next
3. Mode Select
4. Play / Pause
5. RGB Light Mode Select

Charging your NEO 2

1. Connect your NEO 2 to mains power using the included Charging Cable and USB Charger.
2. The Charging Indicator LED will light up to show that your NEO 2 is charging.
3. Once your NEO 2 is fully charged, the Charging Indicator LED will switch off.
This will take between 3 and 5 hours to complete.

Note: If you are playing music while your NEO 2 is charging, we recommend keeping the volume no higher than around 50%.

Controlling the RGB Lights

1. After switching your NEO 2 on, the RGB Lights on both ends of the speaker will automatically switch on.
2. Short Press the RGB Light Mode Selection Button to cycle through the different modes
3. Press and Hold the RGB Light Mode Selection Button to switch the lights off.
4. Short Press the button again to switch them back on.

Using Bluetooth to play music

1. Switch your NEO 2 on using the Power On/Off Switch, the Digital Display will show the letters 'bt' and beep twice to indicate it is in Bluetooth Mode.
2. On your mobile phone, search for Bluetooth devices and select 'Bayan NEO 2' to pair with your NEO 2.
3. Once successfully paired, your NEO 2 will beep three more times.
4. You can now enjoy your music.

Pressing the Previous, Next, and Play/Pause Buttons on your NEO 2 will control music playback as if you had pressed the buttons on your phone.

The volume control on your phone and your NEO 2 are separate. For the best sound quality, set your phone's volume level to maximum, and use the volume control on your NEO to set the listening volume.

Using a microSD card or USB flash disk to play music

1. Switch your NEO 2 on using the Power On/Off Switch.
 2. Insert either a microSD card or USB flash disk into the respective ports on your NEO 2 and it will automatically switch mode and begin to play any music found.
 3. Pressing the Previous, Next, and Play/Pause Buttons on your NEO will control music playback.
 4. Press and Hold the Previous and Next buttons to search through tracks.
-

Using a 3.5mm Aux input to play music

1. Switch your NEO 2 on using the Power On/Off Switch.
2. Insert either a microSD card or USB flash disk into the respective ports on your NEO 2 and it will automatically switch mode and begin to play any music found.
3. Pressing the Previous, Next, and Play/Pause Buttons on your NEO 2 will control music playback.
4. Press and Hold the Previous and Next buttons to search through tracks.

Using a microphone with your NEO 2

1. Plug a Karaoke style microphone with a 6.35mm jack into your NEO 2's 6.35mm Microphone Input.
2. Use the Microphone Volume Control to adjust the Microphone's volume.

A microphone can be used in any of your NEO 2's different modes.

Troubleshooting

NEO 2 will not turn on

Ensure that the battery is charged - connect the power cable to NEO 2 and plug in to a laptop, mobile phone or power bank USB charging source. The charge indicator light will be ORANGE when NEO 2 is charging, and when fully charged will turn GREEN.

I cannot hear any music

Ensure that the volume is turned up on both your source device (phone / mp3 player) and also on your NEO 2. Ensure that NEO 2 does not have a 3.5mm audio cable connected to the AUX input (for Bluetooth listening), or that it the AUX cable is correctly connected for non-Bluetooth sources. Ensure that your source device has the correct output selected (for Bluetooth, select the output as 'Bayan NEO 2')

I cannot pair my Bluetooth media player with my NEO 2

For secure simple pairing to function; your Bluetooth device needs to be in close proximity to your NEO 2 (nominally within 50cm).

Specifications

Bluetooth Version: 4.2 (can pair with devices with Bluetooth version 2.1 or higher)

Profile: A2DP

Effective Range: 10m (30 feet)

Dimensions: 376 x 173 x 186mm (L x W x H)

Weight: 2.08kg

Box Contains

- 1 x Bayan Audio NEO 2 Portable Speaker
- This manual
- Charging cable
- Wall power supply



For a full User Manual and Technical Support
please visit bayanaudio.com