

©2021 Inogen. All rights reserved www.inogen.com

\*If the red light is flashing, unplug the unit and complete steps 2-3 again. If a red flashing light continues after these steps, contact your Equipment Provider.