Task Seating

Assembly Instructions





Task Seating

Assembly Instructions

No tools required.

- 1. Open carton and unpack all components.
- 2. Place chair base upright on floor, stabilising it so it does not move or slide.
- 3. Insert the gaslift & cover into the hole in the chair base.
- **4.** Place the seat with mechanism onto the gaslift, ensuring the underside of the mechanism and top of the gas lift align.
- **5.** Firmly press the seat into the gas lift.
- **6.** Slide the plastic cover off the back bar. Slot the back bar into the opening of the mechanism.
- **7.** Position the plastic cover over the back of the chairs mechanism. Adjust back to desired height and tighten with knob.
- **8.** Sit on the chair to adjust the seat to the correct height and position.

Warning: Failure to follow these assembly instructions can result in product failure, personal injury or property damage.

PARTS KEY:



B Back Bar

Gas Lift

Seat with Mech



Draughting Ring

Assembly Instructions

No tools required.

- 1. Open carton and unpack all components.
- 2. Place chair base upright on floor, stabilising it so it does not move or slide.
- 3. Insert tall gaslift cylinder into chair base by fitting cylinder into hole through base.
- 4. Slide the draughting ring down the tall gaslift, and hand tighten at desired height.
- **5.** Carefully place upper chair assembly onto the gas lift, ensuring the underside of the mechanism and top of the gas lift align. Press down firmly to ensure secure fit.
- 6. Without adjusting seat depth or height, sit firmly in chair to complete assembly.

Warning: Failure to follow these assembly instructions can result in product failure, personal injury or property damage.



