



scottaerator.com  
1-800-928-3745

## Fountain and Aerator Securement

Secure a nylon anchoring line (not provided) to each of the two attached eyebolts. Make sure lines are long enough to extend outwards, 25 feet apart at a 45° angle to the pond or lake bottom.

### Minimum anchor weight

1/3 hp	20 lbs x 2
1/2hp	25 lbs x 2
1hp	35 lbs x 2
1-1/2hp	40 lbs x 2
2hp	50 lbs x 2
3hp	55 lbs x 2

**ALWAYS USE A GFCI  
ALL WIRING SHALL BE PER N.E.C.,  
OR LOCAL ELECTRICAL CODES**

