

customer*CQre*™



Range Hood HS90CSX3 FP AA

Product Code: 80858-A

**Parts Manual** 

# **1** GUIDE TO USING THIS MANUAL

Brand: Fisher & Paykel

Voltage: 220-240V, 50Hz

Model: HS90CSX3 FP AA

Product Code: 80858-A

### Model

- The model covered by this manual is listed on the front cover.
- The information detailed in this manual is subject to change without notice. The latest version is indicated by the reprint date and replaces any earlier editions.

#### **Kit Parts**

Kit components are shown in *italics*. Where a part number is shown against the descriptions for these kit components, they are also available as separate items. In addition, some parts may be supplied with these kits that are not available as separate items, and are therefore either not listed, or a part number is not shown against the part description in this manual.

#### **Parts List Key**

| italics  | Kit components or parts included are shown in italics. Refer to above notes: Kit Parts. |  |
|----------|---|--|
| NI       | As a part reference, indicates the part is not illustrated on the diagram.              |  |
| NOT USED | As a part number, indicates the diagram part reference is not used in this manual.      |  |

**RANGE HOOD ASSEMBLY** 

## Fisher & Paykel Appliances Ltd


PO Box 58-546, Botany 78 Springs Rd, East Tamaki Manukau 2163 New Zealand

tel: (09) 2730660 fax: (09) 2730580 email: customer.care@fp.co.nz

## Fisher & Paykel Customer Services Pty Ltd

PO Box 798, Cleveland, QLD 4163 A.C.N. 003 3335 171 19 Enterprise Street Cleveland, QLD 4163 Australia

tel: (07) 3826 9100 fax: (07) 3826 9164 email: customer.care@fp.com.au



| REF. | PART NUMBER | PART DESCRIPTION               |
|------|-------------|--------------------------------|
| 1    | 792392      | FILTER ALUMINIUM 90            |
| 2    | 792406      | HANDLE STAINLESS STEEL 90      |
| 3    | 792395      | HANDLE WHITE GLASS (HS90)      |
| 4    | 792410      | SWITCH BOX                     |
| 5    | 792437      | SWITCH LIGHT 2 POSITION        |
| 6    | 792438      | SWITCH LIGHT 3 POSITION        |
| 7    | 792390      | FILTER CHARCOAL 60 / 90        |
| 8    | 792411      | GRILL INLET                    |
| 9    | 792414      | MICRO SWITCH ASSEMBLY          |
| 10   | 792416      | VENT OUTLET F2060              |
| 11   | 792447      | ADAPTOR OUTLET VENT 100MM      |
| 12   | 792448      | COVER OUTLET VENT 100MM        |
| 13   | 792449      | COVER OUTLET VENT F2060        |
| 14   | 792415      | BRACKET SUPPORT                |
| 15   | 792444      | BRACKET SUPPORT SMALL 90CM     |
| 16   | 792442      | BRACKET SUPPORT 90CM           |
| 17   | 792408      | SCREW COUNTERSUNK              |
| 18   | 792409      | GUIDE TELESCOPIC               |
| 19   | 792440      | LAMPHOLDER ASSY GU10           |
| 20   | 791822      | LAMP HALOGEN 50W RANGEHOOD     |
| 21   | 792412      | MOTOR FAN COVER ASSY TF5260 LH |
| 22   | 792439      | POWER CORD AA                  |
| NI   | 792489      | SCREWS INSTALLATION HS60 HS90  |
| NI   | 590484      | BOOK USE INSTL HS60 HS90 FP AA |



customer *Care* 

#### www.fisherpaykel.com



Copyright © Fisher & Paykel 2013. All rights reserved. The product specifications in this manual apply to the specific model described at the date of issue. Under our policy of continuous product improvement, these specifications may change at any time. Only use this manual if the product code on the front matches the product code on the serial label of the product.