

**ELBA**  
*by Fisher & Paykel*

# Parts Manual Built-in Oven

**Model:**  
OB60SCMW 2 EL AA

**Product Code:**  
89164-A



care

89164-A



## PRODUCT

**Brand** Elba by Fisher & Paykel  
**Voltage** 220-240v 50 Hz  
**Model** OB60SCMW 2 EL AA  
**Product Code** 89164-A

Description
White, electronic minute timer, Elba handle, Elba knob, 2 pane door

<b>Fisher &amp; Paykel Appliances Ltd</b> 78 Springs Road East Tamaki PO Box 58-732, Botany Manukau 2163 New Zealand Telephone: 09 273 0600 Facsimile: 09 273 0656	<b>Fisher &amp; Paykel Australia Pty Ltd</b> A.C.N. 003 335 171 19 Enterprise Street P O Box 798 Cleveland, Queensland 4163 Australia Telephone: 07 3826 9100 Facsimile: 07 3826 9164
---	--



## CONTENTS

CONTROL PANEL & COMPONENTS .....	6
CHASSIS ASSEMBLY .....	8
DOOR ASSEMBLY .....	10
ELEMENTS AND ACCESSORIES.....	12

### GUIDE TO USING THIS MANUAL

The model covered by this manual is listed on the front cover.

The information detailed in this manual is subject to change without notice. The latest version is indicated by the reprint date and replaces any earlier editions.

The front cover picture shows the type of product and may not necessarily be an exact image of the model covered by the manual.

### Kit Parts


Kit components are shown in *italics*. Where a part number is shown against the descriptions for these kit components, they are also available as separate items. In addition, some parts may be supplied with these kits that are not available as separate items, and are therefore either not listed, or a part number is not shown against the part description in this manual.

### Parts List Key

<i>italics</i>	Kit components or parts included are shown in <i>italics</i> . Refer to above notes: Kit Parts.
NI	As a part reference, indicates the part is not illustrated on the diagram.
NOT USED	As a part number, indicates the diagram part reference is not used in this manual.

# CONTROL PANEL & COMPONENTS

Fisher & Paykel  
appliances




DWG000930

## CONTROL PANEL & COMPONENTS

REF	PART	DESCRIPTION
1	544284P	PANEL CONTROL O/ASSY OB60SCM2
2	574210	SPACER PLASTIC 7MM
3	574406	THERMOSTAT EGO
4	574833P	CLOCK 3BTN LED2000ESK1342-014 KIT
5	574145P	GROMMET RUBBER (PKT 10)
6	574206	BRACKET CLOCK
7	574211	SWITCH FUNCTION (NON MULTI)
8	573950	TRIM DEFLECTOR
9	574213P	BUTTON PLASTIC (SILVER) (PKT 3)
10	574626	KNOB ELBA D0
NI	546362P	WASHER CONTROL PANEL (PKT 10)
11	574207	BEZEL NEON RED
12	574389	NEON L.230MM 240V EM
13	574390	NEON L.600/230MM 230V EM

# CHASSIS ASSEMBLY



Fisher & Paykel  
Appliances


DWGG001649



## CHASSIS ASSEMBLY

REF	PART	DESCRIPTION
1	574862P	OVEN & FRAME ASSY ENAM GPHT 53LT
2	574071	INSULATION SIDE LAMP
3	574070	INSUL WRAP CLASS B TERMOVER
4	574170	INSUL FAN ASY CLASS B TERMOVER (INSUL & FOIL)
5	574072	INSUL REAR CLASS B TERMOVER
6	574205P	FAN KITSET OVEN OB60 (E) (SP)
	<i>Includes</i>	<i>FAN MOTOR &amp; MOUNTING</i>
	<i>Includes</i>	<i>FAN BLADE</i>
	<i>Includes</i>	<i>NUT</i>
7	574169	SPRING REAR INSUL SUPPORT
8	574092	PANEL REAR
9	574910	FLEX MAINS
10	574086	PANEL RIGHT SIDE
11	533061	TERMINAL BLOCK
12	574148P	CLIP CABLE STANDOFF (PKT 2)
13	574182	TRIM ASSY OVEN FRONT RH BK
	<i>Includes 574149</i>	<i>BRACKET HINGE SUPPORT</i>
14	574857	BRACKET ELEMENT LOWER
15	574598	PANEL BASE
16	574277P	KIT FEET/SCREWS (PKT 4)
	<i>Includes 556636</i>	<i>SCREW ST 7X13 TAB MSH PH ZP</i>
17	574083	TRIM FRAME LOWER BK
18	574424	GASKET OVEN 53LT (CUT)
19	574063	GASKET FRAME
20	574087	PANEL SIDE LEFT
21	574183	TRIM ASSY OVEN FRONT LH BK
	<i>Includes 574149</i>	<i>BRACKET HINGE SUPPORT</i>
22	574202P	FAN COOLING (E) (SP)
23	574079	PANEL VENTING UPPER
24	574081	PANEL VENTING LOWER
25	574080	PANEL VENTING MIDDLE
26	574145P	GROMMET RUBBER (PKT 10)
27	574215	PANEL TOP
28	574090	LIMITER 120 CAMPINI
29	574132	CLIP LIMITER
30	574214	CLIP THERMST TUBE HINGED ELMNT
31	574149	BRACKET HINGE SUPPORT
NI	574957	KIT SCREWS FIXING (PKT 4) (INSTALLATION)


# DOOR ASSEMBLY



## DOOR ASSEMBLY

REF	PART	DESCRIPTION
1	574865P	GLASS&BRACKET ASSY FULL EL WH
	<i>Includes</i>	<i>BRACKET DOOR LOWER</i>
	<i>Includes</i>	<i>GLASS DOOR FRONT 60 WH ELBA</i>
2	574075P	KIT BRACKET DOOR LH BK
	<i>Includes 574480</i>	<i>GROMMET DOOR BRACKET (4)</i>
3	574145P	GROMMET RUBBER (PKT 12)
4	574528	HINGE DOOR 063120
5	574227P	GLASS DOOR INNER OB60 (SP)
6	574076P	KIT BRACKET DOOR RH BK
	<i>Includes 574480</i>	<i>GROMMET DOOR BRACKET (4)</i>
7	574074	BRACKET DOOR TOP BK
8	574873	HANDLE ELBA 432 CTS SILVER
9	574678P	SCREW HANDLE M5X12 (PKT 2)
10	574701P	SPACER HANDLE ELBA (PKT 2)
11	574124	GASKET DOOR INNER TOP
12	574874P	SPACER ELBA DOOR (PKT 2)
13	574480P	GROMMET DOOR BRACKET (PKT 10)
NI	574479P	NUT SPIRE NO6P (PKT 10)

# ELEMENTS AND ACCESSORIES



## ELEMENTS AND ACCESSORIES

REF	PART	DESCRIPTION
1	574250	RACK BAKE OB60
2	574778	TRAY BAKING OB60 AL (SP)
3	574251	RACK STEPDOWN OB60
4	574786	RACK GRILL INSERT
5	574841P	TRAY BAKING ENAM GPHT FPI (SP)
6	574851	RACK SIDE OB60
7	574141P	SCREW SIDE WIRE RACK (PKT 4)
8	574067	ELEMENT TOP ASSY HINGED OB60
9	574158	ELEMENT BAKE ASSY ON60 CLASS B
10	574065P	LAMP ASSY REAR 77.222 (25W) (SP)
	<i>Includes 573235</i>	<i>LAMP FLOODLIGHT 230V 252 SES)</i>
11	574066P	LAMP ASSY SIDE 77.722.2104.23 (SP)
	<i>Includes 573235</i>	<i>LAMP FLOODLIGHT 230V 252 SES</i>
12	574870	SHROUD FAN OB60 ENAM GPHT
13	573235	LAMP FLOODLIGHT 230V 252 SES
NI	89098	ACPROD SC SIDE PANELS OB60 V1
NI	542061	BOOK SERVICE & WARRANTY
NI	599758	BOOK USR/INSTL OB60 EL AA