



# Service Manual

MODEL: **AUTU3-F60**. PRODUCT: **600 ELECTRIC OVEN**

**Disclaimer.** The information contained in this service manual is intended for licensed service personnel only.






Whole Door 0102400-SS  
 Whole Door 0102404-WH

PART NUMBER	DESCRIPTION
0102027	Thermostat (double bulb)
0111021	Lamp
0102034	Motor Fan (30W-230V)
0102035	Cooling Fan (18W/22W-220V)
0102039	Hinge
0102049	Rubber Door Seal
* 0102051	Rubber Door Seal
0102614	Safety Device (65degrees)
0102613	Safety Device (140degrees)
0102057	Red Light Cover
0102058	Control Panel Light
0102062	Minute Timer
0102063	Orange Light Cover
0102070	Selector
* 0102075	Rubber Stopper
0102077	Door Handle Support
* 0102400	Whole Door (stainless steel)
* 0102404	Whole Door (white)
0102406	Door Panel (white)
0102408	Handle (white)
0102413	Door Panel (stainless steel)
0102419	Counter Door
0102424	Control Panel (stainless steel)
0102433	Handle (stainless steel)
0102438	Knobs (stainless steel)
0102439	Knobs (white)
* 0102442	Control Panel (white)
0102501	Top Element (2000W-240V)
0102509	Circular Element (2300W-240V)
* 0102600	Oven Rack
* 0102602	Wire Side Rack
* 0102604	Enamel Drip Tray
0102606	Drip Tray Insert
* 0102608	Grill Pan Handle

\* part no longer available



intersource  
SOLUTIONS

PO Box 7785, Baulkham Hills BC, NSW 1755 Australia  
spares@intersource.co | 1300 985 815