



Electrolux

Spare parts list


Cookers
2252

PNC	ELC	Brand	Model	Market
949640788	00	IKEA	LAGAN 30450119	AU

Documentation Centre
Al. Powstancow Slaskich 26
30-570 Krakow
Poland
Fax +48 12 296 95 10

Publication-No.
599835019
2020/01/27
ZO

Built-in hobs,
Gas,
with control elements



Matrix	PNC	ELC	ProdDate	Model
A	949640788	00	20200120	LAGAN 30450119

Pos	Part No.	Matrix	Description
001	140121960193	A	Work top,black,silkscreened,594x510mm
004	140033817010	A	Fixing spring,spark plug,thermocouple
042	3550427045	A	Knob
043	140054095322	A	Push button switch
060	4055381901	A	Nozzle set,LPG, (G30-G31)
060	4055473955	A	Nozzle set,GN, G20-20mbar
061A	140014838035	A	Burner body,auxiliary
061R	140014840031	A	Burner body,rapid
061S	140014839033	A	Burner body,semi-rapid
062A	3540138017	A	Crown,small burner
062R	3540136052	A	Crown,large burner
062S	3540137019	A	Crown,medium burner
063A	8072424032	A	Cap,burner,auxiliary
063R	8072424016	A	Cap,burner,rapid
063S	8072424024	A	Cap,burner,semi-rapid
064	3546196019	A	Grid,pan support
070A	140176557563	A	Gas tap,auxiliary,d=0.28 GN 1.0kPa
070R	140176557589	A	Gas tap,rapid,d=0.48 GN 1kPa
070S	140176557571	A	Gas tap,semi-rapid,d=0.35 GN 1kPa
073	3572079030	A	Impulse generator
074	140013306067	A	Spark plug,ignition,L=400
076	3577334026	A	Sleeve,fixing,tap
077	3540029034	A	Connector,elbow,1/2"
078	140003387010	A	Gas pressure regulator
085	3556230013	A	Cable grommet
090	3570563027	A	Thermocouple,ORKLI L=500mm
090	3570653059	A	Thermocouple,L=275mm
098G	3565193012	A	Gasket,gas,elbow,1/2"
098K	140110283011	A	Sealing,antioverflow gasket
999	140112882034	A	Power cord,Australia,3x0,75mm,1600mm
999	140117160014	A	Tie,fixing,work top,4pcs
999	3305733010	A	Seal,adhesive,ceramic glass,6x2x2900mm
999	3543244028	A	Bolt,2,9x13mm T10
999	3543279016	A	Key,TORX T20-T20
999	3543294031	A	Bolt,gas tap,M4x17 T20
999	50294266007	A	Screw pack,fixing,burner,2,9x13 - 24 pz.