
Thank you for purchasing the Pulsar® APX Smoker V3! In order to ensure safe use, please read all instructions and safety warnings before operating. Failure to follow instructions may result in injury and may void your warranty.





FEATURES

Isolated Airpath Zirconia Mouthpiece Built-in Stir Tool Pure Quartz Lined Chamber Ceramic Power Pad Replaceable Atomizer Auto Shut-off **USB-C Charging**

TECH SPECS

Size: 23mm x 31mm x 81mm Input: DC.5V/1.0A Battery Capacity:1100mAh Class A Lithium Battery Battery & Output: 3.7/8A Atomizer Resistance: 0.4Ω Battery Recharge Cycle Count: 300 Temperature Range: 950-1095°

















CHARGING THE DEVICE

- IMPORTANT: You will need to fully charge your Pulsar® APX Smoker prior to use. Allow approximately 3 hours for the first full charge. NEVER charge the device for more than 24 hours. Allow approximately 1.5 hours for additional recharges.
- A 5V/1.5 Amp USB AC wall adapter is required for charging the
 device. Using the included USB-C charge cord, set the Pulsar APX
 Smoker on its side while charging. Do not let the unit dangle from
 the cord. This puts pressure on the charger plug which can result in
 the unit not charging fully. It is also recommended to NEVER charge
 the device from an automobile power source. Failure to follow
 warnings contained within this manual can result in property damage
 or personal injury and may void the warranty.
- The APX Logo LED will show a charging connection is made by slowly flashing red until fully charged. The indicator will change to solid green when completely charged.
- The device will deliver approximately 1.5 hours of continuous power, depending on use.
- Before using the device it is advised to turn on the unit and allow it to heat up to burn off any of the manufacturing process.
- · Battery level display:
- Green APX Logo = 100-60% Power Level
- Orange APX Logo = 60-20% Power Level
- Red APX Logo = 20-0% Power Level

 Low Battery: APX Logo LED will flash alternating red & green 3 times and the device will not power on.

HOW TO LOAD & OPERATE

- 1. Remove the mouthpiece.
- For best results, fill the chamber with ground material. Use the built-in stir tool with the tamping end to lightly and neatly pack the chamber. Do not pack too tightly. This allows for even heat distribution and makes it easier to stir throughout the Smoker session.
- 3. Once loaded, replace the mouthpiece and turn the unit on by pressing the power button rapidly 5 times (5 Clicks for ON/OFF).
- 4. Once the unit is on, press the power button, or click the power button two times for hands-free mode. The LED will begin pulsing to indicate heating is in progress. The LED will turn solid once it is ready.
- Allow the device to continue heating for approximately 7 seconds longer before inhaling. This ensures the herbs in the chamber are evenly heated, maximizing efficiency.

PRO TIPS

- Occasionally stir herbs and allow the chamber to reheat for 5 seconds between each inhale.
- To maximize efficiency, whenever possible, allow the unit to cool completely.
- · Be sure to turn the unit off when you are done to preserve the material.
- Your Pulsar APX Smoker is equipped with a 5-minute auto shut-off timer to further prevent waste and overheating.

HOW TO CLEAN THE MOUTHPIECE

The metal mouthpiece on the top has a friction fit and can easily be removed by pulling it away from the Smoker body with light force.

- Pour enough isopropyl alcohol into a soaking container to cover the mouthpiece.
- Place the mouthpiece in the container with isopropyl alcohol for one hour.
- 3. Remove and wipe with a cleaning wipe.
- 4. Rinse in cold water and dry with a hand towel or paper towel.

HOW TO CLEAN THE COIL CHAMBER

Since the heating element uses a coil-less heating pad, there is no worry of having to avoid touching exposed heating coils. These steps can be performed while the mouthpiece is soaking.

- Make sure the Smoker unit is turned off and the heating coil element is cool.
- Use an alcohol filled cotton swab or lightly dip a dry cleaning swab in 91% isopropyl alcohol.
- 3. Use the swab to wipe the inside of the coil chamber until clean.
- 4. Unthread and remove the coil from the Smoker body.
- 5. Use the cleaning swab to wipe the coil housing of the Smoker body.
- 6. Re-assemble vaporizer and dry-fire before use.

CLEANING NOTES

- Do not use cleaning solutions, solvents, or other chemicals when cleaning the device. Doing so will result in undesirable tastes or smells and can cause potential health hazards.
- It is a good idea to clean the unit after each use to avoid excessive build-up, which will interfere with the taste and function of the device and may affect warranty status.

IMPORTANT SAFETY WARNINGS

- · Do not expose to extreme temperatures or direct sunlight.
- · Do not drop the device or accessories.
- · Do not drop or submerge in any liquid.
- · Do not modify the electronics in any way.
- This device is intended for adults only. Do not sell or provide to minors. Keep all parts, concentrates, herbs, and liquids away from children and pets. This is not a medical device and is not intended to diagnose, treat, mitigate, cure, or prevent any ailment, disease, or other conditions. Consult a physician before use, especially if you suffer from heart disease or any other medical condition, or if you are pregnant or breastfeeding. Failure to follow any of these instructions could result in product damage, property damage, personal injury, and may void warranty.