



## **Waters Co Ltd. Flushing Instructions** FOR BMP 1000 MODEL

### **When new:**

1. From filter kit remove: Sub mineral cartridge, First stage, Second stage, Main filter, Bio Ceramic block (White stone) & Alkalite Diskette (Brown Far infra-red disc) & Mineral Sub Cartridge.
2. Soak 1<sup>st</sup> Stage Filter only in room temperature water (20° - 30° C) for 10 - 20 minutes.
3. Soak all other components separately (2<sup>nd</sup> Stage, Main Filter, Ceramic, Alkalite Diskette & Sub Cartridge) in cold water for 10 - 20 minutes.
4. 1<sup>st</sup>, 2<sup>nd</sup> & main filters will emit some grey water initially. This is excess carbon powder.
5. Shake 2<sup>nd</sup> Stage & Sub cartridge rinse again, repeat 2 to 3 times until no further excess carbon is emitted)
6. Insert 1<sup>st</sup> Stage (brown filter) cartridge into place in filter system this must be flushed with warm water (20° - 30° C) & may emit an odor initially. (This is from a natural sea based resin which removes the Fluoride) it is harmless & will disappear with continued use or alternatively repeat flushing cycle until odor is no longer present. This process may take a little time & only needs to be done once with each new 1<sup>st</sup> Stage (Brown) filter.
7. Insert 2<sup>nd</sup> Stage Filter & main filter into place.
8. Fill pot another two times with cold tap water and empty.
9. When finished cold flushing, rinse Glass Reservoir under cold clean running water, assemble remainder of components & you are ready to start using.
10. Pre filters (White pads) are under a plastic circular bracket, located in the housing that holds upper (brown filter) in place. To change pre filters see circular plastic grille in centre with small knob protruding upwards. Push to the side with thumb & circular grille will pop out change pads as required when dis-coloured or every 2 – 3 weeks

### **MAINTENANCE**

**CHANGE PRE FILTERS 14 DAYS**

**CHANGE UPPER FILTERS 10 MTHS**

**CHANGE SECOND STAGE FILTER 60 MTHS**

**CHANGE MAIN FILTER 60 MTHS**

Every 6 -12 months take pot apart and wash in warm soapy water, rinse thoroughly after washing  
If your pot has a tap, unscrew this and clean components, take some pipe cleaners and clean inside the tap.

**For replacement filters contact your original supplier:**

**For product support, video instructions, lifetime warranty registration & filter reminder service go to [www.waterscoaustralia.com.au](http://www.waterscoaustralia.com.au)**

### **Contact:**

Waters Co Australia

P: 1300 799 099

F: 03 8648 6824

E: [info@waterscoaustralia.com.au](mailto:info@waterscoaustralia.com.au)