



SEASONAL MAINTENANCE

As seasons change, it is important to remember that your watering systems and water supplies need some extra attention.

WATER SUPPLIES

DRAIN AND STORE

in an empty state if your water supplies will be exposed to freezing temperatures. If not disconnected, the watering system will not be able to drain the tubing and reset properly.



BATTERY WATERING SYSTEMS


PERFORM SEASONAL MAINTENANCE

to your single point watering (SPW) systems on vehicles that are pulled out of service or put into storage for a period of 6 weeks or longer. To winterize the SPW system, simply drain any remaining water from the feed tube and place the male coupler on top of the battery making it the highest point of the system. This will allow any excess water to naturally drain into the system.

Additionally, the following steps need to be followed when bringing your vehicle back into service:

ProFill
Single Point Battery
Watering System

1. After the batteries have been fully charged/equalized, connect the systems to its water supply for 3-5 seconds then disconnect regardless of whether or not the batteries are completely full.
2. Return the vehicle back to normal operation.
3. Place the vehicle back into its regular watering schedule (waiting at least one week until next watering).



MM-036-1220


flowriteTM

www.flow-rite.com • 616.583.1700

Follow us on social media: [in](#) [ig](#) [f](#)