



ARCADIA CEILING LIGHT

Install Guide and Manual


COMPONENTS



x1
Mounting Bracket



x3
Wire Nuts




x2
Screws




Matte Black



Glossy White



Silver



Gold

EASY INSTALLATION

HARDWIRE INSTALLATION WITH BRACKET TO JUNCTION BOX




Turn Power OFF


1. Turn off circuit breaker that provides power to the light switch.
2. Run source wire from existing outlet to the switch location, if not already done.




3. Install compatible junction box (not included). Slot distance for junction box should be 1.65"-3.54" (42mm-90mm).
4. Remove the two ball nuts and their gaskets from the mounting bracket.
5. Using 2x provided screws, install mounting bracket on the junction box.




6. Feed supply wires through junction box.
7. Connect supply wires to ceiling wires with included wire nuts.
 - Black to Black;
 - White to White;
 - Ground to Ground.



8. Secure ground wires to mounting bracket under screw.
9. Tuck all wires into junction box.



10. Attach ceiling fixture to mounting bracket with ball nuts and gaskets.



Turn Power ON

11. Install two light bulbs.
12. Turn on circuit breaker and test the light.

WARNING

- To reduce the risk of fire, electric shock or physical injury:
- This product should be installed in accordance with the applicable installation code by a person familiar with the construction and operation of the product and the hazards involved.
- Abide by related regional and local laws or regulations.
- Do not install directly over a heat source (stove, etc.).
- Proper grounding is required to ensure safety.
- Not suitable for wet environments; this fixture is damp-rated.
- Check for shipping damage prior to install. If the product is damaged, do not use it.
- Turn off the switch and circuit breaker before installing this light fixture.
- This fixture should not be installed on a radiant heating ceiling or on the surface of combustible material, nor should this light be covered by flammable material.
- Use safety precautions. Safety eyeglasses and gloves are recommended.

SPECIFICATIONS

Voltage	120V
Frequency	60Hz
Suitable for Locations Ingress	Damp
Housing	Steel
Warranty	5 Years
Dimmable	Compatible with dimmable bulbs