

Bungibundi

USER MANUAL



WWW.BUNGIBUNGI.COM

Thank you for purchasing a Bungi Bungi!

Your Bungi Bungi comes fully assembled when purchased from a Bungi Bungi authorised dealer. These instructions are intended to detail some important points vital for the safe and efficient use of your bike and the adjustment of the bike to accommodate your child's development.

Please retain these instructions for future reference!

If you do not receive this bicycle fully assembled - we strongly advise to have a bicycle mechanic have it assembled!



Going for a ride? Share the happy moments!
Tag us on Instagram @bungibungibikes
#bungibungibikes !



Anatomy of a Bungi Bungi



- | | |
|-------------------------|--------------------------|
| (A) Stem | (G) Saddle |
| (B) Brake Levers | (H) Seat Clamp |
| (C) Headset | (I) Pedals |
| (D) Brakes | (J) Cranks |
| (E) Front Wheel | (K) Belt |
| (F) Rear Wheel | (L) Gear Clickbox |

Getting your bicycle ready to ride

The bicycle comes 85% assembled in a box. To get it ready for riding, a few things have to be done beforehand. These instructions will guide you how to do it properly.

1 Installing the saddle

Sit your child on the bicycle and fasten the seat clamp with a 5mm hex key at a position where your child can comfortably reach the ground with their feet.

Remember - kids bikes are not fitted in the same way as adult bikes! It is especially important that your child can reach the ground to minimize the risk of falling. Once the child has become accustomed to the bicycle you can start raising the height of the saddle!





2 Handlebars

The handlebar comes detached from the bicycle. To install the handlebar - unscrew the four screws on the stem with a 4mm hex tool, set the handlebar and close the bolts in a zig-zag pattern to ensure even pressure on the handlebar.

Make sure the handlebar is set in the middle of the stem and in the correct angle before you fully tighten the screws to 5-7Nm.

To change the height of the handlebar, you can switch out the spacers on the fork. Unscrew the stem side bolts with a 4mm hex tool, unscrew the top cap with a 5mm hex tool and rearrange the spacers to your needs.

To assemble everything - put on the top cap and tighten it to the point that there is no more headset bearing play. Thereafter adjust the stem position parallel to the front wheel and tighten the stem screws.



3 Brakes and Brake Levers

Make sure to adjust the angle of the brake levers so that your child does not have to strain their wrists by setting the lever too low.

You can adjust the brake lever position with a 2mm hex tool and the adjustment screw.

After any lever adjustments - make sure that the brake cable has enough length for the brakes to work properly!





4 Belt tension

To avoid belt skipping and extra wear on the drivetrain parts - a regular check of belt tension is required.

To adjust belt tension - remove the Shimano clickbox from the rear axle with a 5mm hex tool, make sure not to damage the shifting pin when removing/installing the clickbox. Loosen the bolts of the hub with a 15mm wrench tool.

Once the rear hub can freely move in the dropouts - you can adjust belt tension with the adjusters that fit a 3mm hex tool.

Make sure the rear wheel is aligned properly in the frame, otherwise, it might interfere with the frame or the brakes might not work properly.

To secure the wheel - tighten the axle bolts with a 15mm wrench tool and install the Shimano clickbox back.

If the wheel is mounted correctly, no brake or gear adjustments will be necessary.



5 Wheels

To ensure the longevity of the bicycle and safe riding - a regular check of the wheels is required.

Make sure that:

- There is always enough air pressure in the tyres.
- The wheels are true and have no loose spokes.
- The hubs have no play in the bearings and are securely fastened in the frame/fork.
- Brake pads are true to the rim's braking surface.





6 Pedals

To install the pedals you will either need a 15mm wrench tool or a 6mm hex tool (depending on the pedal model). Identify the left pedal from right with the letters "L" and "R" respectively written on the end of the pedal axle.

Install the right pedal in the right crank - drivetrain side.

Install the left pedal in the left crank - non-drive side.

NOTE: Make sure to apply grease on the pedal axle threads before installing them! The left pedal has a counter-clockwise thread! Do not try to install it clockwise!



7 Maintenance

A clean bicycle does not just look better, but also prevents extra wear on moving parts and helps you detect worn or damaged parts quicker.

Just like any other piece of equipment - it will run longer and smoother, if it is properly lubricated and cleaned!

We recommend using bicycle or car shampoos for cleaning the bike together with a brush and sponge.

Do not use a jet wash! This will damage the sealed bearings!





8 Safety

Always use a helmet!

Accidents can happen even in your own backyard. It is very important to wear a helmet at all times while cycling! And not just for children!

Riding in the dark

All bicycles come with a full set of reflectors that have to be mounted on the bicycle and kept clean at all times.

While riding in the dark you have to use a proper set of battery powered bicycle lights!

Riding in bad weather

While riding in slippery/muddy conditions, use extra precautions and make sure that the brakes work properly. A set of mud guards will also help you to stay cleaner.

This bicycle is not intended for adult use!

Failure to comply with this can result in injury or part damage that might not be visible at first, but can result in a crash later!

Make sure to comply with the traffic and bicycle laws of your country! Be friendly to others in traffic and ride safe!

Warranty

Warranty coverage on your Bungi frame and components extends for TWO YEARS from the date of purchase while owned by the original retail purchaser.

This warranty does not cover:

1. Normal wear and tear. Including consumables such as tyres, grips, inner tubes and cables.
2. Any damage, failure or loss caused by accident, misuse, neglect, abuse, failure to follow instructions or warnings in the owners' manual or manuals supplied with the bike referring to original equipment fitted.
3. Any damage, failure or loss caused by use of bicycles for stunt riding, acrobatics or other similar activities, or in any other manner for which they were not designed. Bending of frames, forks, handlebars, seat posts or wheel rims can be a sign of misuse or abuse.
4. The original owner shall pay all labour charges connected with the repair or replacement of all parts. Under no circumstances does this limited warranty include the cost of shipment or transportation to or from an authorised Bungi Bungi distributor or retailer

Limitations

Only bikes sold, assembled and collected from an authorised Bungi Bungi dealer will be eligible for warranty. The foregoing warranties are in lieu of and exclude all other warranties not expressly set forth herein, whether expressed or implied by operation of law or otherwise, including but not limited to any warranties of merchantability or fitness for a particular purpose. Bungi Bungi shall in no event be liable for incidental or consequential losses, damages or expenses in connection with its bicycle products. Bungi Bungi's liability hereunder is expressly limited to the replacement of goods not complying with this warranty or, at Bungi Bungi's discretion, to the amount equal to the purchase price of the product in question.

Procedures

- Warranty service will be performed by Bungi Bungi or a Bungi Bungi authorised dealer. Proof of purchase must be provided. Transportation to and from Bungi Bungi, a Bungi Bungi distributor or a Bungi Bungi authorised dealer is the responsibility of the purchaser.
- Bungi Bungi will have the option of either repair or repayment of an amount equal to the purchase price of the product.
- In the event Bungi Bungi elects to replace a defective frame, a new frame of equal or greater value will be provided. The new frame may not be the exact model purchased. Bungi Bungi is not responsible for dealer labour charges for component changeovers when a frame is replaced.
- If you elect to repair a defective product yourself or use the services of someone other than an authorised Bungi Bungi dealer, Bungi Bungi will not be liable for any damage, failure or loss caused by the use of such unauthorised service or parts.



HAVE A GREAT RIDE!



Have questions? Drop us a line info@bungibungi.com

Van Oldenbarneveltstraat 132, 3012GW, Rotterdam, The Netherlands
+31(0)625354421