



**N MOBILE
WARMING**
PERFORMANCE HEATED APPAREL



RIDGE GLOVE
USER MANUAL

FOLLOW US



WWW.MOBILEWARMING.COM

Welcome to Warmth. Stay Warm, Stay Comfortable



F.I.R Technology

Patented Mobile Warming® technology is specially engineered for cold environmental conditions. Mobile Warming® comprehensive heating solutions keep you warm and comfortable. The exclusive Mobile Warming® heating system utilizes F.I.R (Far-Infrared) heat and ultra-fine metal fiber heating elements powered by lightweight, rechargeable, and powerful Lithium-Ion batteries. As heat builds Mobile Warming® advanced materials reflect and direct heat back towards the body ensuring that you stay warm. The combination of unique materials, construction techniques, and innovative design results in the most advanced heated gear available.

Introduction

Thank you for purchasing our Ridge Glove. To ensure proper use and care of your garment and our Mobile Warming products please read this user manual prior to use.

Includes

- One - Pair of Ridge Gloves

⚠ WARNING

- Only use the MW battery(s) provided with garment(s).
- Do not attempt to disassemble or alter any part of this garment.
- Do not store MW battery(s) below -4F(-20°C).
- Do not allow MW batteries or charger to come in contact with water or other liquids. If water or other liquids enter the battery interior immediately unplug the garment from the battery. Continued use of the garment may result in fire or electrical shock.
- Do not place this garment near a heat source or expose battery(s) to direct flame or heat as the battery(s) may explode.
- Disconnect MW battery pack from the garment(s) when not in use. Garment(s) will discharge battery even when power is off.

NOTICE


Ridge Jacket is required to power the Ridge Glove's heating system.

Quick Start Guide


- 1- Fully Charge Ridge Jacket battery to 100%.
 - 2- Follow Ridge Jacket instructions for connecting Lithium-Ion battery to jacket.
 - 3- Locate power port on Ridge Gloves. (See drawing A)
 - 4- Locate Power Lead located inside the cuffs of each sleeve of the Ridge Jacket. (See drawing B)
 - 5- Plug power lead connector into power port of glove and repeat for other glove. (See drawing C)
- Note: Ridge Gloves heating will be controlled by the Ridge Jacket touch control button.

If you plan to not use the Ridge Gloves or Ridge Jacket for more than a few days, unplug both batteries from the gloves.

Connecting to Ridge Jacket



Ridge Glove Heat Ratings



Power Ratings Based on Fully Charged Ridge 12v Battery.

Ridge Gloves only Work with Men's or Women's Ridge Jacket



Wash Instructions



To wash, disconnect the battery(s) from the power lead/wire harness, and remove battery from garment(s).

Hand Wash Only. Wipe down with a wet cloth and mild detergent.
Do Not Bleach. Do Not Iron, Do Not Dry Clean, Do Not Tumble Dry,
Do Not Wring.
Lay flat air dry only. Do not machine dry.

Warranty Terms

*Our warranty applies only to the original purchaser and only for items purchased from an authorized Mobile Warming Dealer or Authorized distributor retail partner.

Limited Two Year Warranty (Garment)

When you purchase a Mobile Warming brand product from an authorized Mobile Warming retailer within the United States or Canada both the construction and electrical heating components of the product are warranted to be completely free from factory defects in materials and workmanship for two (2) year from the date of purchase. If any failure in the construction or the heating function of any

WWW.MOBILEWARMING.COM

Mobile Warming product purchased from an authorized Mobile Warming dealer within the United States and Canada occurs due to the manufacturer's defect within two years of the purchase of the product, the product will be repaired at no charge.*

90 Day Rechargeable Battery & Charger Warranty

Mobile Warming Gear rechargeable Lithium-ion battery packs and chargers are under warranty from factory defect for 90 days from the initial purchase date. Mobile Warming will repair or replace any battery or charger found to be defective under normal use within the 90 day warranty period.

*Costs associated with shipping the item in under warranty is the responsibility of the purchaser.

Warranty Exclusions

Any damage caused to any Mobile Warming products by misuse, abuse, improper care, accident, normal wear and tear, use of non-mobile warming battery systems, and or the natural breakdown of materials over an extended period of time and use are not covered in this warranty. Any alterations or repairs (attempted or otherwise) performed on any Mobile Warming product voids any and all warranties offered by Mobile Warming for that particular item. Mobile Warming products are technical athletic apparel and is not intended for use as work wear or for use in strenuous or demanding circumstances or extreme conditions.

How to initiate a Warranty Claim

First, please ensure that your product is covered under warranty according to the terms above. Then simply have a digital copy of your dated proof of purchase ready and contact our friendly customer service team at info@mobilewarming.com, informing us that you would like to initiate a warranty claim for repair, briefly explaining the nature of your claim, with your dated proof of purchase attached. Our customer service team will then follow up with you within two business days of receiving all of the necessary information with an email containing a Return Authorization number, return instructions and the return shipping address in order to return with your defective item.