

WIRING DIAGRAM




NOTE: Replacement parts can be purchased from wenproducts.com, or by calling our customer service at **1-847-429-9263**, M-F 8-5 CST. Parts and accessories that wear down over the course of normal use are not covered by the three-year warranty. Not all parts may be available for purchase.




No.	Part No.	Description	Qty.
1-1	56380i-0101	Crankcase Subassembly	1
1-2	56380i-0102	Flat Washer, 10mm	1
1-3	56380i-0103	Connector, Oil Drain Hose	1
1-4	56380i-0104	Oil Drain Hose	1
1-5	56380i-0105	Trigger	1
1-6	56310i-1106	Bolt, M5x16	2
1-7	56380i-0107	Crankcase Side Shield	1
1-8	56310i-1201	Bolt, M6x16	3
1-9	56310i-0211	Engine Oil Sensor	1

No.	Part No.	Description	Qty.
1-10	56310i-0210	Flanged Hex Nut, M10	1
1-11	56380i-0111	Bearing, 6305P53	1
1-12	56310i-0306	Oil Seal	1
1-13	56380i-0113	Starter Motor	1
1-14	56380i-0114	Bolt, M6x28	2
1-15	56380i-0115	Protective Cover	1
1-16	56380i-0116	Ignition Coil	1
1-17	56380i-0114	Bolt, M6x28	2
1-18	56380i-0118	Oil Dipstick	1
1-21	56310i-1201	Bolt, M6x16	3









No.	Part No.	Description	Qty.
3-1	56200-1202	Bolt, M6x12	4
3-2	56380i-0302	Cylinder Head Cover Subassembly	1
3-3	56380i-0303	Cylinder Head Cover Gasket	1
3-4	56310i-0104	Spark Plug (Torch F6RTC, NGK BPR6ES)	1
3-5	56310i-0106	Cylinder Head Bolt, M8x60	4
3-6	56380i-0306	Breather Tube	1
3-7	DF450i-0307	Cylinder Head Subassembly	1

No.	Part No.	Description	Qty.
3-8	56310i-0109	Bolt, M8x34	2
3-9	56380i-0309	Stud Bolt, M6x105	2
3-10	56380i-0310	Cylinder Head Gasket	1
3-11	56380i-0311	Pin	2
3-12	56380i-0312	Limiter	1
3-13	56200-1202	Bolt, M6x12	1
3-14	56380i-0314	Breather Gasket	1
3-15	56380i-0315	Breather Plate	1
3-16	DF452iX-0316	Temperature Sensor	1









No.	Part No.	Description	Qty.
5-1	56310i-0501	Piston Ring Assembly	1
5-2	56310i-0505	Piston Pin Clip	2
5-3	56380i-0503	Piston	1
5-4	56310i-0504	Piston Pin	1
5-5	56380i-0505	Connecting Rod	1

FIG. 7. RECOIL STARTER




No.	Part No.	Description	Qty.
7-1	56380i-0701	Recoil Starter And Shroud Assembly	1
7-2	56200-1202	Bolt	4
7-3	56200-1202	Bolt	4
7-4	56400iX- 0704	Starter Pulley	1
7-5	56200-0420	Recoil Starter Handle	1
7-6	56400iX- 0702	Clamp	2
7-7	56380i-0707	Shroud	1
7-8	56380i-0708	Recoil Starter Assembly	1

FIG. 6. VALVE TRAIN & CAMSHAFT SUBASSEMBLY




No.	Part No.	Description	Qty.
6-1	56380i-0601B	Camshaft Assembly	1
6-2	DF450i-0602	Valve Set	1
6-3	DF450i-0603	Seal Guide	1
6-4	56310i-0604	Valve Spring	2
6-5	56380i-0605	Valve Spring Seat	2
6-6	56310i-0606	Valve Lock Clamp	4
6-7	56310i-0607	Valve Tappet	2
6-8	56380i-0608	Valve Lifter Subassembly	2
6-9	56380i-0609	Valve Rocker Arm	2
6-10	56380i-0610	Rocker Shaft	2

FIG. 8. CARBURETOR ASSEMBLY




No.	Part No.	Description	Qty.
8-1	56380i-0801	Carburetor Insulator Gasket	1
8-2	56380i-0802	Carburetor Insulator Plate	1
8-3	56380i-0803	Carburetor Gasket	1
8-4	DF452iX-0804	Carburetor Assembly	1
8-5	56200-1305	Fuel Strainer	1
8-6	56380i-0805	Clamp	1
8-7	56380i-0806	Fuel Tube	1
8-8	56380i-0805	Clamp	1
8-9	56400iX-0809	Rubber Jacket	1
8-10	DF400i-0806	Clamp	2
8-11	DF400i-0807	Pressure Hose 1	1
8-12	DF400i-0808	Pressure Hose 2	1






No.	Part No.	Description	Qty.
9-1	56310i-1101	Flywheel Nut, M14-1.5	1
9-2	56380i-0902	Impeller	1
9-3	56310i-1103	Bolt, M6x60	3
9-4	56380i-0904	Rotor	1
9-5	DF452iX-0905	Stator	1
9-6	56380i-0906	Flat Washer, 6mm	3
9-7	56380i-0907	Wiring Clamp	1
9-8	56310i-0207	Bolt, M5x20	2
9-9	56400iX-0909	Tension Disc	1
9-10	56400iX-0910	Flanged Hex Nut, M5	2






NO.	Part No.	Description	Uty.
10-1	56380i-1001B	Air Filter	1
		Assembly	
10-2	56380i-1002	Intake Tube	1
10-3	56380i-1003	Intake Tube Clamp	2
10-4	56310i-1420	Bolt, M6x25	2
10-5	56380i-1005	Secondary Air Filter	1
10-6	56200-0506	Nut, M6	2
10-7	56310i-0901	Air Filter Gasket	1




No.	Part No.	Description	Qty.
11-1	56380i-1101	Shroud	1
11-2	56380i-1102B	Muffler Cover Support	1
11-3	56380i-1103	Impeller	1
11-5	56380i-1105	Muffler Assembly	1
N.P.	56380i-1115	Spark Arrestor	1
11-6	56380i-1106	Muffler Gasket	1
11-7	56310i-1010	Nut, M8	2
11-8	56380i-1108	Muffler Bracket	1
11-9	56310i-1009	Bolt, M8x16	5
11-11	56310i-1004	Bolt, M8x20	1
11-12	56380i-1112	Bolt, M6x35	1
11-13	56200-0508	Bolt, M6x12	3
11-14	56380i-1114	Bolt, PT4x13	1

FIG. 12. FUEL TANK ASSEMBLY




No.	Part No.	Description	Qty.
12-1	56380i-1201	Fuel Tank Assembly	1
12-2	56380i-1202	Fuel Gauge	1
12-3	56380i-1203	Fuel Tank Outlet	1
12-4	56200-1202	Bolt, M6x20	4
12-5	56380i-1205	Flat Washer, 6mm	4
12-6	56380i-1206	Bushing	4
12-7	56380i-1207	Fuel Tank Damper	4
12-8	56380i-1208	Fuel Tank Cap	1
12-9	56380i-1209	Fuel Strainer	1
12-10	56380i-1210	Fuel Tank Sleeve	1
12-11	56200-0413	Fuel Level Sight Glass	1
12-12	56380i-1212	Upper Cover	1
12-13	56380i-1213	Cover Plug	1
12-14	56400iX-1214	Rubber Jacket	1



No.	Part No.	Description	Qty.
13-1	DF452iX-1301	Engine Frame Assembly	1
13-2	56380i-1302	Battery Case	1
13-3	56380i-0313	Bolt, M6x12	3
13-4	56380i-1304	Battery, 12V, 1.6Ah, Li-ion	1
13-5	56380i-1305	Battery Bracket	1
13-6	56380i-1306C	Quick-Connector Wiring Harness, Battery	1
13-7	56380i-1307C	Quick-Connector Wiring Harness, Starter Motor	1
13-8	56310i-1420	Bolt, M6x25	3
13-9	56310i-1421	Rubber Jacket	3
13-10	56310i-1419	Bushing	3
13-11	56450i-1311	Inverter	1
13-12	56310i-1201	Bolt, M6x16	1
13-13	56380i-1313	Rubber Sleeve	1
13-14	56380i-1314	Carbon Tank Mounting Bracket	1
13-15	56380i-1315	Carbon Tank	1
13-16	56380i-1316	Carbon Tank Hose, Primary	1
13-17	56380i-1317B	Air Filter Hose	1
13-18	56380i-1318	Carbon Tank Hose, Secondary	1
13-20	56380i-1320	Clamp	1
13-21	56380i-1320	Clamp	1
13-22	DF452iX-1322	Flanged Hex Bolt, M8x30	4


NO.	Part No.	Description	Uty.
13-23	56380i-1323	Front Handle	1
13-24	56380i-1324	Handle	1
13-25	56200-0406	Bolt, M5x12	2
13-26	56380i-1326	Screw, M4x8	1
13-27	56380i-1327	Grounding Wire	1
13-28	GN625iX-1430	CO Sensor Module	1
13-29	56400iX-1329	Security Socket Head Cap Screw, M4x25	2
13-30	56400iX-1330	Mounting Bracket	1
13-31	DF400i-1329	Hose Clamp	1
13-32	DF400i-0806	Clamp	2
13-33	DF400i-1330	LPG Hose	1
13-34	56380i-0313	Bolt	2
13-35	56400iX-1332	Flat Washer, 5mm	1
13-36	DF400i-1328	LPG Regulator	1
13-37	DF400i-1332	Primary LPG Regulator Hose Assembly	1
13-38	56400iX-1331	Bolt, M6x10	1
13-39	DF452iX-1339	Remote Receiver Module	1
13-40	56380i-0313	Bolt, M6x12	2
13-41	56400iX-1330	Mounting Bracket	1
13-42	DF452iX-1342	CO Sensor Engine Controller Module	1
13-43	56310i-1106	Bolt, M5x16	2



No.	Part No.	Description	Qty.
14-1	56200-0615	Self-Tapping Screw, ST4.2x16	3
14-2	56380i-1402	Switch Subassembly	1
14-3	56200-0621b	Cover Plate	1
14-4	56200-0624B	Adjustment Spring	1
14-5	56200-0623	Steel Ball	1
14-6	56200-0502	Bolt, M6x14	1
14-7	56200-0628	Fuel Cock Assembly	1
14-9	56380i-1409	Bolt, M5x16	6
14-10	DF400i-1425	Panel Seat	1
14-11	56200-0302	Screw, M5x12	6
14-12	DF452iX-	Control Panel	1
14-12	1412ASM	Subassembly	
14-13	56200-0514	Screw, M4x16	1
14-14	DF400i-1428	Knob	1
14-15	56200-0425B	Bolt, M5x16	1
14-16	56200-0427B	Nylon Nut, M5	1
14-17	56380i-1417	Blocker	1
14-18	56380i-1418	Battery Cover	1
14-19	56380i-1419	Multimeter	1
14-20	56380i-1424	Parallel Port, Positive	1
14-21	56380i-1429	DC Breaker, 10A	1
14-22	DF875iX-1430	Battery Charger Module	1
14-23	56380i-1423	Parallel Port, Negative	1


No.	Part No.	Description	Qty.
14-24	DF875iX-1423	Remote Pairing Button	1
14-25	56380i-1425	12V DC Outlet	1
14-26	DF452iX-1426	Engine Start/Stop Button	1
14-27	56380i-1421	NEMA 5-20R Duplex Outlet	1
14-28	56380i-1428	NEMA TT-30R Outlet	1
14-29	56380i-1422	Switch Subassembly	1
14-30	56380i-1427	Grounding Nut	1
14-31	56380i-1430	AC Breaker, 20A	1
14-32	56380i-1432	Rectifier Bridge	1
14-33	56200-0103	Clamp	1
14-34	56380i-1434	Fuel Tube	1
14-35	56380i-1435	Clamp	1
14-36	56400iX-1436	CO Sensor LED Indicator	1
14-38	DF400i-1439	Nut, M14-1.5	1
14-39	56310i-1415	Screw, M4x8	1
14-40	DF400i-1436	LPG Inlet	1
14-41	DF400i-1437	LPG Inlet Plug	1
14-42	56400iX-1438	Control Panel Wiring Harness	1
14-43	56380i-1420	Reset Button	1
14-44	56380i-1431	Switch Subassembly	1

FIG. 15. HANDLE ASSEMBLY



No.	Part No.	Description	Qty.
15-1	56380i-1501	Handle Tube	1
15-2	56380i-1502	Left Rotation Arm	1
15-3	56380i-1503	Right Rotation Arm	1
15-4	56380i-1504	Left Handle Con- nector	1
15-5	56380i-1505	Right Handle Con- nector	1
15-6	56380i-1506B	Left Handle Con- nector Seat	1
15-7	56380i-1507B	Right Handle Con- nector Seat	1


No.	Part No.	Description	Qty.
15-8	56200-0517	Bolt, M6x12	2
15-9	56380i-1509	Bolt, M6x10	4
15-10	56310i-1201	Bolt, M6x16	4
15-11	56310i-1807	Nylon Nut, M6	2
15-12	56380i-1512	Flat Washer, 6mm	2
15-13	56380i-1513	Connector Fastener	2
15-14	56380i-1514	Flat Washer, 13mm	6
15-15	56380i-1515	Positioning Block	2
15-16	56380I-1516	Washer, 12mm	4
15-17	56380i-1517	Flat Washer, 12mm	2



No.	Part No.	Description	Qty.
16-1	56380i-1601	Left Cover	1
16-2	56200-0406	Bolt, M5x12	4
16-3	56380i-1603	Left Shell	1
16-4	56380i-1604	Right Shell	1
16-5	56380i-1605	Right Cover	1
16-6	56200-0408	Nut, M6	8
16-7	56380i-1607	Bolt, M6x20	8
16-8	56200-0515	Fuel Tank Rubber Sleeve	4
16-9	56200-1202	Bolt, M6x12	8
16-10	56380i-1610	Recoil Starter Guide Subassembly	1


No.	Part No.	Description	Qty.
16-11	56200-0302	Screw, M5x12	2
16-12	56200-0420	Recoil Starter Handle	1
16-13	56380i-1613	Right Maintenance Door	1
16-14	56400iX-1614	Access Door Knob	1
16-15	56380i-1417	Blocker	1
16-16	56400iX-1616	Spring Clamp	1
16-17	56380i-1617	Wheel	2
16-18	56380i-1618	Wheel Axle	2
16-19	56380i-1619	Nut, M5	16

FIG. 17. BASE PLATE



No.	Part No.	Description	Qty.
17-1	56380i-1701	Baseplate	1
17-2	56380i-1702	Engine Frame Damper Seat	4
17-3	56310i-1201	Bolt, M6x16	4
17-4	56200-0408	Nut, M6	4
17-5	56380i-1705	Reinforcement Plate	1
17-6	56200-1202	Bolt, M6x12	2
17-7	56310i-1407	Cover Plug	1
17-8	56380i-1619	Nut, M5	4
17-9	56380i-1709	Cushion	1
17-10	56380i-1710	Left Support	1
17-11	56380i-1711	Right Support	1
17-12	56310i-1409	Left Engine Frame Damper	2
17-13	56310i-1411	Right Engine Frame Damper	2
17-14	56310i-1412	Bolt, M8x40	4
17-15	56310i-1404	Nut, M8	10
17-16	56380i-1716	Crankcase Airflow Manifold	1
17-17	56380i-1717	Air Filter Support	1
17-18	56200-1202	Bolt, M6x12	2

FIG. 18. MUFFLER COVER



NOTE: Replacement parts can be purchased from **wenproducts.com**, or by calling our customer service at **1-847-429-9263**, M-F 8-5 CST. Parts and accessories that wear down over the course of normal use are not covered by the three-year warranty. Not all parts may be available for purchase.

No.	Part No.	Description	Qty.
18-1	56380i-1801	Outer Muffler Cover	1
18-2	56200-0406	Bolt, M5x12	6
18-3	56380i-1803	Heat Insulator	1
18-4	56380i-1804	Inner Muffler Cover	1
18-5	56200-0406	Bolt, M5x12	6

ACCESSORIES

	No.	Part No.	Description	Qty.
	N.P.	DF400i-HA36	High Altitude Kit (3000 - 6000 ft)	1
	N.P.	DF400i-HA68	High Altitude Kit (6000 - 8000 ft)	1
İ	N.P.	DF875iX-1432	Remote Control	1
	N.P.	DF452iX-1445	12V DC Automotive to USB Adapter	1

WARRANTY STATEMENT

WEN Products is committed to building tools that are dependable for years. Our warranties are consistent with this commitment and our dedication to quality.

LIMITED WARRANTY OF WEN PRODUCTS FOR HOME USE

GREAT LAKES TECHNOLOGIES, LLC ("Seller") warrants to the original purchaser only, that this WEN consumer product will be free from defects in material or workmanship during personal use for a period of three (3) years from date of purchase or 500 hours of use; whichever comes first. Ninety days for all WEN products if the tool is used for professional or commercial use. Purchaser has 30 days from the date of purchase to report missing or damaged parts. Parts and labor are covered for one (1) year under this limited warranty; parts only are covered for three (3) years under this limited warranty.

SELLER'S SOLE OBLIGATION AND YOUR EXCLUSIVE REMEDY under this Limited Warranty and, to the extent permitted by law, any warranty or condition implied by law, shall be the replacement of parts, without charge, which are defective in material or workmanship and which have not been subjected to misuse, alteration, careless handling, misrepair, abuse, neglect, normal wear and tear, improper maintenance, improper storage, incorrect lubricants / fuels, or other conditions adversely affecting the Product or the component of the Product, whether by accident or intentionally, by persons other than Seller. To make a claim under this Limited Warranty, you must make sure to keep a copy of your proof of purchase that clearly defines the Date of Purchase (month and year) and the Place of Purchase. Place of Purchase must be a direct vendor of Great Lakes Technologies, LLC. Purchasing through third party vendors, including but not limited to garage sales, pawn shops, resale shops, or any other secondhand merchant, voids the warranty included with this product. Contact techsupport@wenproducts.com or 1-847-429-9263 with the following information to make arrangements: your shipping address, phone number, serial number, required part numbers, and proof of purchase. Damaged or defective parts and products may need to be sent to WEN before the replacements can be shipped out.

Upon the confirmation of a WEN representative, your product may qualify for repairs and service work. When returning a product for warranty service, the shipping charges must be prepaid by the purchaser. The product must be shipped in its original container (or an equivalent), properly packed to withstand the hazards of shipment. The product must be fully insured with a copy of the proof of purchase enclosed. There must also be a description of the problem in order to help our repairs department diagnose and fix the issue. Repairs will be made and the product will be returned and shipped back to the purchaser at no charge for addresses within the contiguous United States.

HIS LIMITED WARRANTY DOES NOT APPLY TO ITEMS THAT WEAR OUT FROM REGULAR USAGE OVER TIME, INCLUDING FILTERS, SPARK PLUGS, VOLTAGE REGULATORS, BRUSHES, GASKETS, O-RINGS, WHEEL KITS, BATTERIES, RECOIL STARTERS, HIGH PRESSURE HOSES, SPRAY GUNS, ETC. ANY IMPLIED WARRANTIES SHALL BE LIMITED IN DURATION TO THREE (3) YEARS FROM DATE OF PURCHASE. SOME STATES IN THE U.S. AND SOME CANADIAN PROVINCES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU.

IN NO EVENT SHALL SELLER BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES (INCLUDING BUT NOT LIMITED TO LIABILITY FOR LOSS OF PROFITS) ARISING FROM THE SALE OR USE OF THIS PRODUCT. SOME STATES IN THE U.S. AND SOME CANADIAN PROVINCES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATION OR EXCLUSION MAY NOT APPLY TO YOU.

THIS LIMITED WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS WHICH VARY FROM STATE TO STATE IN THE U.S., PROVINCE TO PROVINCE IN CANADA AND FROM COUNTRY TO COUNTRY.

THIS LIMITED WARRANTY APPLIES ONLY TO ITEMS SOLD WITHIN THE UNITED STATES OF AMERICA, CANADA AND THE COMMONWEALTH OF PUERTO RICO. FOR WARRANTY COVERAGE WITHIN OTHER COUNTRIES, CONTACT THE WEN CUSTOMER SUPPORT LINE. FOR WARRANTY PARTS OR PRODUCTS REPAIRED UNDER WARRANTY SHIPPING TO ADDRESSES OUTSIDE OF THE CONTIGUOUS UNITED STATES, ADDITIONAL SHIPPING CHARGES MAY APPLY.

NOTES	

NOTES	

