

12, 24 & 36" LED TUBE SETUP GUIDE

WARNING: Please refer to local and state laws for the proper use of this product! Improper installation of electrical products such as lighting could cause damage to a vehicle's electrical system or connected devices. Practice extreme caution and follow all established safety procedures. This product could require the handling of high voltage wiring. Electricity could cause injury or death. Professional installation is recommended. Lit Lightz will not be held responsible for any damage or cost whether direct or indirect incurred by the consumer in relation to any Lit Lightz Product. Lit Lightz reserves the right to alter or amend any portion of the aforementioned warranty above.


TESTING THE INFINITY GLOW LED TUBES

1. Before installing please connect all LED tubes to the two connector power converter driver included in your kit, connected the Bluetooth controller to the small three-pin connector located on the power harness (grey box) Once you have connected the tubes and controller, connect the driver to the power converter (grey box)
2. Once you have connected all tubes and controller. With a external 12V power source, connect the red wire (power) and black wire (ground) and fully test and make sure all LED tubes are working accordingly.

BLUETOOTH CONTROLLER SETTINGS

- Download LED Hue app (Android & Apple)
- Open app, scan for devices and look for "litlightz" or "SP110E"

Settings: GRB SK6812 Pixels:
100-150



ADDITIONAL INFORMATION

Please note, the LED tubes max flexibility is an 80-degree angle. Adding more flex will potentially break the PCB board inside. Any modifications like cutting will void the warranty. No DRL or Turn signal functions come with this kit. This kit does not include headlight assembly or housing. Professional installation is recommended.

QUESTIONS?

PLEASE CONTACT US AT SUPPORT@LITLIGHTZ.COM M - F 9 AM - 5 PM