

US UK

Dear user

Thank you for choosing REDDRAGON product. To protect your rights and for better customer service, please read the following warranty rules carefully.

1. Within 18 months of purchase date, repair is guaranteed for failure due to electrical circuit problems. Other damages, such as disassembly, hard impacts, submersion into water, plugging into improper current or voltage, and damage caused by natural disasters such as fire, flood, or earthquake are not included.
2. Consumable parts (such as foot pads) and spare parts replacement are not included in our warranty.

1

How to plug in

Plug type C cable to USB cable with keyboard and PC, keyboard is plug and play, no need driver.

Combination keys function

FN + **【1 !】** = F1
FN + **【2 @】** = F2
FN + **【3 #】** = F3
FN + **【4 \$】** = F4
FN + **【5 %】** = F5
FN + **【6 ^】** = F6
FN + **【7 &】** = F7
FN + **【8 *】** = F8
FN + **【9 (】** = F9
FN + **【0)】** = F10
FN + **【- _】** = F11
FN + **【= +】** = F12
FN+ **【{ }】** = Insert
FN+ **【}]】** = DEL
FN+ **【: ;】** = Home
FN+ **【" '】** = End
FN+ **【. >】** = PgUp
FN+ **【/ ?】** = PgDn
FN+ **【Esc】** = `~
FN+ **【Esc】** + **【Shift】** = ~
FN+ **【A】** = Left
FN+ **【W】** = Right
FN+ **【S】** = Down
FN+ **【D】** = Up

2

Backlight setting

FN+ **【Alt_R】** : Switch over 14 backlight patterns.
FN+ **【Space】** : Turn ON/OFF the backlight.
FN+ **【M】** : Adjust backlight brightness (Total 5 levels).
FN+ **【,<】** : Adjust backlight rotating speed(Total 5 levels).
FN+ **【ESC】** :Back to defaulted setting.
FN+ **【Win】** :Lock Win key, repeat to unlock.
FN+ **【BackSpace】** : Press FN+[BackSpace] into the recording mode, All keys light OFF, press again FN+ **【BackSpace】**, LED of CAPS key twinkle, Press the desired key for favor light color, Press FN+[BackSpace] to save the setting.

FAQ

1. If the keyboard doesn't respond, please check if the keyboard's USB cable is correctly inserted into the corresponding USB port on the computer, or try another USB port on the computer.
2. If you spill liquid on the keyboard, please unplug the keyboard's USB cable from the computer immediately. Wipe off excess liquid and put the keyboard in a warm and ventilated place. Make sure the keyboard is dried naturally before the next use.



3

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

4



REDRAGON

FIZZ WIRED 60% 8K RAPID TRIGGER
MAGNETIC SWITCH KEYBOARD
WITH RGB BACKLIGHT

Mechanical Gaming Keyboard
Operating Instructions