

US UK Dear user Thank you for you choosing  Brand, to protect your rights and for better customer service, we ask that you note our warranty rules. 1. Within guaranty period, repair is guaranteed for failure due to electrical circuit problems. Man-made damages, such as disassembly, hard impacts, submersion into water, plugging into improper current or voltage, and damage caused by natural disasters such as fire, flood, or earthquake are not included. 2. Consumable parts (such as foot stick) and spare parts replacement are no included in our warranty. 3. Please fill out the warranty card. Warranty card is valid with the stamp of the retailer. 4. This warranty card will not be reissued if lost. Please keep it in a safe place. <td> OS support Windows XP/Vista/Win7/Win8/Win10 How to connect the keyboard with a computer Wired Connection Slide the ON/OFF switch on left side of the keyboard to OFF. Take out the USB A to USB Type C cable in the package and connect the keyboard with your computer,Press FN+5(USB) key ,the LED marked with M twinkle in 5 times indicated the conencting sucessful. The computer will recognize and configure the keyboard automatically. Once the keyboard is powered up, charging begins. The LED marked with M lights on red. It will turn to white when keyboard is fully recharged. 2.4G Wireless Connection 1. Slide the ON/OFF switch on left side of keyboard to ON. 2. press [FN]+[4] for about 3 seconds, the LED marked with M flashes quickly in green, plug the USB receiver into any available USB port on your computer within 20 seconds. The computer will recognize and configure the keyboard automatically. 3. The indicator will flash on Red when the battery is low. Please recharge the keyboard in time by plug type C cable into computer or it will turn off automatically soon, Please note LED marked with M will be light on Red while charging, it turn to Green when charging completed(In 2.4g connecting mode). </td> <td> Bluetooth Connection 1. Slide the ON/OFF switch on left side of keyboard to ON. 2. Press [FN]+[1](or [2]/[3] for other Bluetooth devices), the LED marked with M flashes in blue (or cyan/magenta for the others). 3. Turn on Bluetooth and scan for available devices on your computer or smart phone. It will find “BT3.0Keyboard or BT5.0 KB” device. Select one of them to get connected with it automatically. 4. The indicator will flash in Red when the battery is low. Please recharge the keyboard in time by plug type C cable into computer or it will turn off automatically soon, Please note LED marked with M will be light on Red while charging, it turn to cyan/magenta when charging completed(In Bluetooth connecting mode). Function Introduction 1. With standard USB and 2.4G/BT connections, the keyboard can be used on computers without any software or driver installation. 2. There are 20 backlight effects. 3. Commands of key combinations with [FN] key. [FN]+[Ins]: Change backlight mode. There are 20 backlight effects. [FN]+[Del]: Change back light color. [FN] + [←]: Slow down the running speed of backlight . [FN] + [→]: Add up the running speed of backlight. [FN]+[TAB]: Turn the backlight to white. [FN] + [Win]: Disable or enable the [Win] key. [FN]+ [W]: Switch the original W/A/S/D to arrow keys and right arrow keys to W/A/S/D, press again to restore. [FN] + [1]: Select Bluetooth device one (for Bluetooth connection). </td> <td> [FN] + [2]: Select Bluetooth device two (for Bluetooth connection). [FN] + [3]: Select Bluetooth device three (for Bluetooth connection). [FN] + [4]: Change to 2.4G wireless connection. Press and hold the [FN]+[4] for 3 seconds to pair the keyboard with its receiver. [FN] + [5]: Switch to Wired connection. [FN] + [ESC]: Set the keyboard to default setting. Scroll button function Scroll button is place on right upcorner of keyboard for volume adjustment and keyboard backlight brightness adjustment function. Backlight brightness adjustment: Press  key, it is light on White color, Scroll button can switch in different brightness level. Volume adjustment: Press key  the key light's OFF, scroll button can be switch the volume level. Multimedia function on F9-F12 FN+9 : Browser FN+10: Research FN+11: Calculator FN+12: E-mail Shortcut key function  Previous track  Next track  Play / Pause </td>	OS support Windows XP/Vista/Win7/Win8/Win10 How to connect the keyboard with a computer Wired Connection Slide the ON/OFF switch on left side of the keyboard to OFF. Take out the USB A to USB Type C cable in the package and connect the keyboard with your computer,Press FN+5(USB) key ,the LED marked with M twinkle in 5 times indicated the conencting sucessful. The computer will recognize and configure the keyboard automatically. Once the keyboard is powered up, charging begins. The LED marked with M lights on red. It will turn to white when keyboard is fully recharged. 2.4G Wireless Connection 1. Slide the ON/OFF switch on left side of keyboard to ON. 2. press [FN]+[4] for about 3 seconds, the LED marked with M flashes quickly in green, plug the USB receiver into any available USB port on your computer within 20 seconds. The computer will recognize and configure the keyboard automatically. 3. The indicator will flash on Red when the battery is low. Please recharge the keyboard in time by plug type C cable into computer or it will turn off automatically soon, Please note LED marked with M will be light on Red while charging, it turn to Green when charging completed(In 2.4g connecting mode).	Bluetooth Connection 1. Slide the ON/OFF switch on left side of keyboard to ON. 2. Press [FN]+[1](or [2]/[3] for other Bluetooth devices), the LED marked with M flashes in blue (or cyan/magenta for the others). 3. Turn on Bluetooth and scan for available devices on your computer or smart phone. It will find “BT3.0Keyboard or BT5.0 KB” device. Select one of them to get connected with it automatically. 4. The indicator will flash in Red when the battery is low. Please recharge the keyboard in time by plug type C cable into computer or it will turn off automatically soon, Please note LED marked with M will be light on Red while charging, it turn to cyan/magenta when charging completed(In Bluetooth connecting mode). Function Introduction 1. With standard USB and 2.4G/BT connections, the keyboard can be used on computers without any software or driver installation. 2. There are 20 backlight effects. 3. Commands of key combinations with [FN] key. [FN]+[Ins]: Change backlight mode. There are 20 backlight effects. [FN]+[Del]: Change back light color. [FN] + [←]: Slow down the running speed of backlight . [FN] + [→]: Add up the running speed of backlight. [FN]+[TAB]: Turn the backlight to white. [FN] + [Win]: Disable or enable the [Win] key. [FN]+ [W]: Switch the original W/A/S/D to arrow keys and right arrow keys to W/A/S/D, press again to restore. [FN] + [1]: Select Bluetooth device one (for Bluetooth connection).	[FN] + [2]: Select Bluetooth device two (for Bluetooth connection). [FN] + [3]: Select Bluetooth device three (for Bluetooth connection). [FN] + [4]: Change to 2.4G wireless connection. Press and hold the [FN]+[4] for 3 seconds to pair the keyboard with its receiver. [FN] + [5]: Switch to Wired connection. [FN] + [ESC]: Set the keyboard to default setting. Scroll button function Scroll button is place on right upcorner of keyboard for volume adjustment and keyboard backlight brightness adjustment function. Backlight brightness adjustment: Press  key, it is light on White color, Scroll button can switch in different brightness level. Volume adjustment: Press key  the key light's OFF, scroll button can be switch the volume level. Multimedia function on F9-F12 FN+9 : Browser FN+10: Research FN+11: Calculator FN+12: E-mail Shortcut key function  Previous track  Next track  Play / Pause
---	--	---	---

Macro recording function There are 4 profiles keys from M1 to M4 , each profile can assign with 5 macro keys from G1 to G5, total 20 group macro recording. 1. Press M key (M1/M2/M3/M4) to set a profile group, the key lights ON. 2. Press MR key (MR key lights ON),then press G key (G1/G2/G3/G4/G5),the key lights ON. 3. Record the desired keys. 4. Press MR key to complete recording (MR key lights OFF). For example: M1→ MR → G1 → ABC→ MR How to play Macro 1. Choose the profile group by press M key from M1 to M4. 2. Press the Macro key from G1 to G5. For example : M1→ G1(ABC). How to delete Macro 1. Choose the profile group by press M key from M1 to M4 (The key backlighting in flash). 2. Press MR key (MR key backlighting in flash). 3. Double press G keys from G1 to G5 (The key lights OFF). 4. Press MR key to save(MR key lights OFF). How to recharge the keyboard Find the USB A to USB type C cable in the packaging ,plug the keyboard and connect it with computer for charging, the LED indicator(M) of keyboard will be turn to red. Remark: The LED indicator (M) will turn to red when keyboard is out of battery.	Swap functions of [W][A][S][D] and arrow keys 1. Press and hold the [FN] key, and then press the [W] key to interchange the function of the four letter keys [W][A][S][D] and the four arrow keys [↑][↓][←][→]. 2. Repeat the above operation to resume the previous setting. FAQ 1. If the keyboard doesn’t respond, please check if the keyboards USB cable is correctly inserted into the corresponding USB port on the computer, or try another USB port on the computer. 2. If you spill liquid on the keyboard, please remove keyboards USB cable from the computer immediately. Wipe up excess liquid and put the keyboard in a warm place (for instance, under a lamp) to let the keyboard dry naturally before using again. 	FCC Statement Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: -- Reorient or relocate the receiving antenna. -- Increase the separation between the equipment and receiver. -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. -- Consult the dealer or an experienced radio/TV technician for help This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1)this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. California Proposition 65  WARNING: Risk of Cancer from [Name of one or more chemicals known to cause cancer] And Reproductive Harm From [Name of one or more chemicals known to cause reproductive toxicity] Exposure - www.P65Warnings.ca.gov	 REDRAGON HORUS WIRED /2.4G /BT MECHANICAL GAMING KEYBOARD  Please scan here to download user manual Wired /2.4 /BT Mechanical Gaming Keyboard Operating Instructions
--	---	--	---