




Button Instructions

- 1** Left Button
- 2** Right Button
- 3** Scroll Wheel
- 4** Rapid Fire
- 5** Forward
- 6** Backward
- 7** DPI+
- 8** DPI-
- 9** Light Mode
- 10** User Mode





Lighting Instructions

1. User mode indicator light: Located below the Scroll Wheel.

(Indicator light will flash 3 times when switching user modes.)

- Red..... User mode 1
- Blue User mode 2
- Green..... User mode 3
- Purple User mode 4
- Yellow User mode 5

2. DPI Switch Indicator Light: Located below the Scroll Wheel.

(Indicator light will be up for 2 seconds when switching DPI gears.)

- Red..... Gear 1 (500 DPI)
- Blue..... Gear 2 (1000 DPI)
- Green..... Gear 3 (2000 DPI)
- Purple..... Gear 4 (3000 DPI)
- Yellow Gear 5 (4000 DPI)