




Spacer Plate for Side Mount Adapter Plate (For BMS Jack Plate)

Hardware:

A (1) Spacer

Installation Tools:

- 3/4" Socket with Ratchet
- 3/4" Wrench



Product Quality Assurance

JL Marine Systems, Inc. assures that this product is made with the finest quality materials and is free from manufacturer defects.

Please inspect this product immediately prior to installation.

If defects are apparent, please contact JL Marine Systems, Inc. Warranty Department at 813-689-9932 immediately.

Please read all instructions carefully for proper product installation. JL Marine Systems, Inc. is not responsible for improper installation of product.


Note: JL Marine Systems, Inc. recommends that adapter plates be installed by an authorized Power-Pole® dealer. To find a dealer near you go to power-pole.com

Installation Instructions

- Step 1** Locate the pre-drilled holes underneath the decal stickers **Fig. 1**
Note: If you are unable to find the pre-drilled holes please use the attached Template from BMS included. Skip Steps 2 and 3 if pre-drilled holes were found.
- Step 2** Check on the inside of jack plate where hole is to be drilled for any obstructions and for clearance issues of hardware to be installed.
Note: Bolts and hardware not included with spacer plate.
- Step 3** Drill a 1/2" hole into each of the marked hole locations insuring to keep the drill bit straight.
- Step 4** Now place the spacer plate over the drilled holes spanning the recessed area of jack plate.
- Step 5** Finish by following the side mount adapter plate bolt set instructions specific to your jack plate.

Figure 1

Bolt hole locations and recessed area of jack plate.



For Technical Support Call 813-689-9932 opt 2