
GUBI

for S-Table Dining Table - Fixed









1.

Unpack the table, and remove the top by loosening the six screws with a philips screwdriver.




2.

Insert minifx to connect the legs.




Connect the legs to the frame using supplied screws.




5.

Tighten the six screws.



6.

Stand the table up.





CARE INSTRUCTIONS

VENEER

For dusting and light cleaning use a soft, dry cloth. For further cleaning, use a soft cloth that is firmly wrung in clean water for gently wiping the surface, and then immediately use a dry cloth to wipe the surface again. If more thorough cleaning is necessary, use a mild liquid soap dissolved in water on a firmly wrung cloth to wipe the frame. Afterwards, repeat the process with clean water as described above



For enquiries contact GUBI A/S - CVR: 17940384 Klubiensvej 7-9. 2150 Nordhavn. Copenhagen, Denmark T +45 69 15 60 60 – gubi@gubi.com GUBI.COM

Assembly Instructions S-Table Dining Table fixed.