

Quick Start Guide

Intelligent Cyclone Deodorizer (Rechargeable Version CC502)



Step 1

Activate the device

Press and hold the Activation Button for 2 seconds, the device will activate with the blue light flashing twice.

Step 2


Turn on / Turn off the device

- Tap the Touch Switch to turn the device on and start operation.
- Long press the Touch Switch for 5 seconds to turn off the device and stop its operation.

After turning on the device

Blue breathing light : the device is operational.


Red breathing light : the device needs to be charged.



The initial battery level of the device is below 30%, it is recommended to charge it before using.

Hanger

- Choose a dry, clean and flat surface.
- Remove the backing paper, press the hanger firmly for 10 seconds, then let it stand for 5 minutes.
- Align and rotate clockwise the device at the recess on the hanger, until you hear a 'crack' sound, indicating the device is successfully mounted.



- Begin by the Fresnel indicator points to the right.
- Insert it into the recess, and then rotate it clockwise.

! 1. Both Battery-Powered Mode and Direct Plug-In Mode are all workable.

2. When charging the device

- A red breathing light indicates the battery level is below 10%;
- A blue breathing light indicates it's charging;
- A steady blue light indicates the battery is fully charged.

3. If the device is not going to be used for a long period

First turn it off, and then press and hold the Activation Button for 5 seconds. After the red light flashes twice, the device will enter a deactivated state.