

SYBRILLO

BATTERY

■ USER'S GUIDE

EN **Get familiar with Sybrillo
BATTERY.**

You can read and download the User's Guide in your language on Sybrillo's website:

www.sybrillo.com/downloads

FR **Familiarisez-vous avec la
BATTERIE de Sybrillo GO.**

Vous pouvez lire et télécharger le Guide d'utilisation dans votre langue depuis le site Web de Sybrillo :

www.sybrillo.com/downloads

ESP **Familiarízate con la
BATERÍA de Sybrillo.**

Puedes leer y descargar la guía de usuario de Sybrillo en tu idioma en la página:

www.sybrillo.com/downloads

DE **Mach dich mit der
BATTERIE von Sybrillo
vertraut.**

Du kannst dir das Benutzerhandbuch in deiner Sprache auf der Sybrillo-Website ansehen und es herunterladen:

www.sybrillo.com/downloads

HU **Ismerje meg a Sybrillo
BATTERY-t!**

Ez a használati útmutató online elolvasható és le is tölthető az ön választott nyelven a Sybrillo weboldaláról:

www.sybrillo.com/downloads

TABLE OF CONTENTS

PRODUCT INTRO	5
PRODUCT OVERVIEW	6
MOUNTING THE BATTERY	8
POWERING UP	10
MAINTENANCE	14
COMPATIBILITY	16
TROUBLESHOOTING	17
SPECIFICATION	18
DISCLAIMER + WARRANTY	19



PRODUCT INTRO

The Sybrillo BATTERY is the power supply unit for your device.

With its smart battery and charging control system you can quickly charge your battery and using the USB Type-C port, it's possible to use the BATTERY to power other (USB-compatible) devices such as your action camera or even your phone.


We kindly ask you to read this Guide to learn how to best use the BATTERY so that you can get the most out of it.

PRODUCT OVER — — VIEW



MOUNT — —ING THE BATTERY

1. Place the **BATTERY** under your device, with its electric connector facing up.
2. Position it to overlap the base, then push it up towards the base of your Sybrillo device. You will hear a **click sound** when the **BATTERY** is firmly connected to the device.
3. To unmount the **BATTERY**, simultaneously press the two release buttons located on the sides of the product and gently pull the **BATTERY** away from your Sybrillo device.



Position it to overlap the base, then push it up towards the base. You will hear a click sound.

POWER — — ING UP

Important Information and Warning

Do NOT leave the BATTERY connected to the charging device or outlet after it was charged as overcharging may diminish its capacity. Use the supplied charging cable to charge the BATTERY. Do NOT attempt to open the case of the BATTERY as it may lead to electric failure and/or injury.

- Lift the covering lid off the charging port.
- Connect the BATTERY to a laptop or a USB power outlet using the provided charging cable.
- Fully charge the BATTERY before using it.
- Once the charging is complete, mount the BATTERY on your Sybrillo device: hold the device by the lower part in your hand and long-press the ON/OFF Function select button on the BATTERY for 3 seconds. The device turns on and goes into NORMAL mode.

LED Indicators

The LEDs on the BATTERY communicate various information.

TURNING SYBRILLO GO ON:

All LEDs light up for 3 seconds.

BATTERY READING:

To read the BATTERY's current charge, press the power button once.

Each LED represents 20% battery charge;


- If the charge level is 100%, all 5 LEDs light up for 2 seconds,
- If the charge level is 20% only one LED lights up for 2 seconds.

CHARGING:

LEDs will light up and fade out in consecutive order, repeatedly. During charging you can start a battery reading with the same light signals mentioned under "BATTERY READING".

TURNING OFF:

All LEDs blink rapidly for 3 seconds.



If the charge level is 100%, all 5 LEDs light up for 2 seconds. If the charge level is 20% only one LED lights up for 2 seconds.

MAINTEN - - ANCE

Your Sybrillo BATTERY needs very little maintenance – it's designed to work for you for a long time.

If your BATTERY gets wet or even submerged, it will endure it for a limited time. Once it's not exposed to water, wipe it dry with a clean cloth. Do not use a hair dryer or a heat gun, or a high-pressure water gun, as extensive heat and extensive water impact may damage the plastics and/or compromise the electronics.

Should your device become dirty, clean it with a soft, slightly wet fiberless cloth.

If your BATTERY is submerged in salt water, rinse it with a little freshwater to make sure that sea salt does not leave any residue that would damage the electronic components or hinder them in working perfectly.

If you encounter any problems or have questions regarding your Sybrillo BATTERY, please visit our website: **help.sybrillo.com**.

COM — — PATI — — BILITY

The Sybrillo BATTERY is only compatible with Sybrillo action camera stabilizer units.

The BATTERY works as a **power bank**: through the USB connection, it's possible to charge your other devices from it, via a USB cable.

TROUBLE — SHOO — — TING

Should you encounter any problem with your Sybrillo, visit our website for frequently asked questions or our direct customer service.

For help please visit:
help.sybrillo.com

SPECIFICATION

Number of cells	2
Operating voltage	Nominal voltage range: 7.4-8.4 V
Overcurrent protection	Yes
Battery construction	Charging controller integrated
Capacity	850 mAh
Cell type	Li-Po
Environmental tolerance	Operates best between -15 and 40°C, or between 5 and 104°F
Safety systems	Integrated over-current, over-voltage and over-charge protection

DISCLAIMER + WARRANTY

BATTERY Information and Warnings

When you aren't charging your BATTERY, we recommend that you disconnect it from the power source. Please do not leave the BATTERY connected to a charger for longer than 12 hours, since overcharging may shorten its life and is also an unnecessary waste of electricity.

Battery disposal

Once your BATTERY reaches the end of its lifespan, we kindly ask you to dispose of it in a safe and responsible way. Please check the rules regarding battery disposal in your area and act accordingly. In the name of the environment: thank you!

Water tolerance

Sybrillo devices are designed **watertight**. This means your device will function in rainy and/or snowy environments for a limited time. Submerging the BATTERY is not recommended. We advise NOT to use the BATTERY in activities where water can exert major impacts on the device.

Warranty information

Sybrillo guarantees that the devices and accessories you purchased are free from any defects or damages both in materials and functionality upon reception of the product(s). Under normal use and with the User's Guide's contents in mind, the purchase warrants a **1 year period of full warranty** for the customer.

Warranty limitations and exclusions

The limited warranty is only granted if conditions of proper use are met by the Customer.

Any defects or damage which result from accidents, misuse, not intended manner of use, abnormal and/or

unadvised conditions, unadvised manner of storage, prolonged exposure to liquid, moisture, chemicals, sand or dirt, neglect, or unnecessary physical and/or electrical and/or magnetic stress **cancel the warranty.**

Scratches, dents, cracks and any visual cosmetic **damage caused by the customer or any third party limits and/or cancels the warranty.**

The warranty is canceled in case of:

- **any defect or damage** resulting from use of excessive force or inflicted by the use of any sharp object;
- the **device's serial number removed**, damaged, altered or made illegible;
- the device shows **marks of ordinary wear and tear**;

- any defect or damage resulting from **improper and/or unadvised operation, maintenance, attempted service, or adjustments**;
- **defects or damage resulting from external causes** such as traffic accidents, collisions with an object, fire damage, flooding, dirt, windstorm, lightning, earthquake, exposure to severe weather conditions, theft, unadvised use of any electrical source.

Sybrillo reserves the right to examine and decide on replacement claims on each order individually.

Sybrillo's Replacement Policy

Sybrillo (Redwood City, CA 94063) guarantees a refund or a replacement of your BATTERY with the conditions below.

A refund of your Sybrillo BATTERY can be requested within 7 days counted from the actual reception date of the product. In case of a refund, the cost of reshipping of the product to our address is charged to the customer.

We can accept refund requests if your product was not activated and is in new condition without any marks of wear, with all belonging accessories and packaging shipped back alongside with the main unit.

In case the purchase was not conducted through our website or has been conducted as a pre-purchase, the 7-day refund period is not applicable.

If you discover any manufacturing defect of the product or any of its accessories, a replacement will be granted, depending on your choice. Please contact customer service at: **help.sybrillo.com**

Refunds

Sybrillo will NOT grant you a refund if the refund was requested beyond 7 days of the product's actual reception, or accessories of the product are lost or damaged, or if the device itself was damaged or is not in its new condition both optically and physically.

Furthermore, **if the proof of purchase (receipt) cannot be provided**, Sybrillo is not obliged to issue a refund. In case the BATTERY was modified or altered in any way, neither refund nor replacement will be issued.

In case the BATTERY was modified in any way by the User/Purchase a refund will NOT be granted.

Disclaimer and Safety Instructions

To make sure your video-capturing experience is as good and productive as possible, we kindly ask you to abide the following instructions regarding your and the BATTERY's general safety.

- **Read and comprehend the User's Guide** as it covers all important questions regarding the product.
- **Do not break open, modify or abuse your BATTERY.** Treat your device with care and protect it from harsh environmental impacts.
- Before turning on your device make sure there is **no dirt, sand or any other residue** from previous use that may restrict its optimal functionality.

- Before turning on your device make sure **you are holding it in the intended way** – by the BATTERY in your palm. Should you hold the device in any other way, **make sure your fingers do not restrict any moving parts** as this will lead to lower performance and may result in unnecessary mechanical stress or even injury.
- **Do not throw** your device and **avoid dropping it**.
- Hold the device in your hand before powering it up. **Make sure your fingers are not obstructing the arms of the gimbal** to avoid personal injury and/or mechanical stress.

- Before every charging, **make sure the charging port is free of debris, sand and dust** as these may negatively affect charging performance as well as cause electrical problems within the device.
- Though the BATTERY was designed with no small parts that are removable, **please keep your device away from small children**.
- **Your device cannot function with a depleted BATTERY**. Refer to the section of this guide on the BATTERY and its charging, and charge the BATTERY accordingly.
- **Do not use the BATTERY for other than its original purpose** which is to power or charge the connected device.

- Use your Sybrillo products exclusively with original Sybrillo BATTERIES.

- Do not expose your device to heat.

This includes but is not limited to putting it in hot devices such as ovens, microwave ovens and tumble driers.

- Do not short the connectors of your Sybrillo BATTERY as this could lead to serious electric malfunction and/or personal injury!

- Do not expose your device to strong magnetic fields.

Sybrillo is not affiliated with, endorsed by, or in any way associated with GoPro® Inc. or its products and services. GoPro®, HERO, and their respective logos are trademarks or registered trademarks of GoPro® Inc.



facebook.com/sybrillo



twitter.com/sybrillo



youtube.com/sybrillo



instagram.com/sybrillo



linkedin.com/sybrillo



SYBRILLO

www.sybrillo.com