

# QUI — — CK START GUIDE



SYBRILLO



- 1.** The Sybrillo app is available on the App Store and on Google Play.
- 2.** Mount the Battery under the gimbal. Place the Battery on the bottom part of the gimbal unit, then slide it into its place. A click sound will indicate when the Battery is firmly in place. To release the Battery, simultaneously press and hold the two eject buttons on its side, pull it back and away from Sybrillo GO and lift it off.
- 3.** Unscrew the thumb screw. Secure your action camera in its mounting fixture. Connect the fixture with Sybrillo GO's small arm. The camera's back must face the vertical arm. Screw the thumb screw back into its place and make sure it's a tight fit.
- 4.** Power on your Sybrillo Go! Hold it firmly, then long-press (3 sec) the button located next to the battery indicator LEDs. The gimbal will activate and move the camera into the home position.
- 5.** Connect your action camera and your Sybrillo GO with the Sybrillo app. The first time you use your Sybrillo GO, it needs to be configured. The app will then remember your device.
- 6.** Hold Sybrillo GO and try the joystick's analog stick movements and click functions.
- 7.** Go shoot!

### For iPhone:

available on App Store



### For Android:

available on Google Play

