

USER MANUAL.

**Generations
Pendulum
Caliber 2824-2**

Your Fromanteel watch

To maintain the precision and reliability of your Fromanteel watch, we advise you to mind the following (practical) guidelines.

Preventive maintenance

Dust and dirt tend to collect in gaps in the back of the case, so clean the watch occasionally. For the case: use a toothbrush with soapy water and a soft cloth for drying. Avoid contact with solvents, detergents, perfumes, cosmetic products, since they may damage the bracelet, the case or the gaskets. Avoid speakers or refrigerators, since these have strong magnetic fields. Avoid shocks whether thermal or other. Avoid temperatures above 60°C (140°F), below 0°C (32°F) or extreme temperature changes. Store your watch in a dry place when not using it.

Adjusting your Caliber 2824-2:


These instructions apply for a Caliber 2824-2 movement, as found in The Pendulum™ watch. Contact us for more info or questions on: service@fromanteel.nl

Water-resistant:

Your Fromanteel watch is 5 ATM water-resistant.

Service centers:

At Fromanteel, we value a continued relationship with you. Your watch comes with an international warranty for a period of two years. Please contact us at service@fromanteel.nl with your questions and/or comments.



Caliber 2824-2

Change time + date

Winding: With the crown in Position 0, wind the watch about 30 times. This will power the main spring of your watch. The rotor will continue to wind the watch as you wear it and keep the watch going. The watch has a power reserve of about 38 hours.

Setting the time: Pull the crown out to Position 2 to set the time (hours and minutes). The rotor will stop in place when the crown is pulled out to this position.

Setting the date: Pull the crown out to Position 1 to set the date.

