




www.scentbetter.com

AromaCasa Deluxe USER MANUAL




Please read this manual carefully before using.

Thank you for choosing our product,
you will have an enjoyable experience.

SPECIFICATIONS

| | |
|---------------|---|
| Model | AromaCasa Deluxe |
| Colour | Dark or light wood grain |
| Capacity | 400ml |
| Run Time | Up to 9 Hrs Intermittent/6 Hrs Continuous |
| Features | Timer setting 1 Hrs/3 Hrs/6 Hrs. 7 changing LED lights - Red, Orange, Yellow, Green, Cyan, Blue and Purple |
| Coverage | 400 square feet |
| Rated power | 12 W |
| Adapter power | 100-240v, 24v0.5A |

WHAT'S INCLUDED




AromaCasa Deluxe Aroma Diffuser AC Adapter Measuring cup User Manual

HOW IT WORKS


The AromaCasa Deluxe Diffuser uses high frequency ultrasonic technology that vibrates water inside the unit, dispersing an ultra-fine mist into the air. When essential oils are added, they are immediately released into the air providing health benefits and helping to ionize the air. It can be used in a bedroom, living room, office area, or anywhere you want to create a relaxing environment.

HOW IT WORKS




HOW TO ADD ESSENTIAL OIL

1. Plug the adapter cord into the base first, then plug the unit into the wall. Do not move once unit has been filled with water. Take off the lid.
2. Add few drops of essential oil.
3. Using your measuring cup, fill the base with 350ml (13.6 oz) of distilled or purified/filtered water (not cold). Do not use tap water. Do not overfill.
4. Replace the lid. Turn on.



HOW TO OPERATE

Modes of Operation



Press Light

1. Rotating
2. Fixed color
3. OFF (Long press light button to turn off the light)

Press Mist

1. 1H timer
2. 3H timer
3. 6H timer
4. Continuous
5. Intermittent

TROUBLESHOOTING

| SYMPTOM | CAUSE | SOLUTION |
|-------------------------------|--|---|
| No mist | Using incorrect water, tap water with high mineral content Unit is out of water | Use distilled or purified water |
| No mist or Little mist | Unit needs to be cleaned. Oils are clinging to ceramic disc or sensor Water lever is higher than max level line | Clean unit as advised in instructions with clean water & clean ceramic disc/sensor with brush or swab Clean unit and fill water 1/2 way to fill line and add additional water after getting mist Remove excess water and restart the diffuser |

TROUBLESHOOTING

| SYMPTOM | CAUSE | SOLUTION |
|---|--|--|
| Blinking Lights | Water level indicator is dirty Condensation may have accumulated inside the top | Clean unit as advised. Gently tap the top cover to allow water to drop back into the tank. |
| Unit will not stop running even though empty | Water lever indicator is dirty | Clean unit as advised. Pay particular attention to swabbing the sensor/disc inside the bottom of the unit. |
| No misting and unit is spraying water | Water is too cold | Change to warmer water. |

CAUTION: Keep away from children and pets. This diffuser has a 1 year manufacturer warranty.

ESSENTIAL OIL RECIPES

Balancing Blends

DAILY BALANCE

Add the following oils to diffuser:
2 drops of Geranium Oil
2 drops of Rose Oil
2 drops of Clary Sage Oil

MIND EASE

Add the following oils to diffuser:
3 drops of Lavender Oil
3 drops of Peppermint Oil
3 drops of Chamomile Oil

SPRING CLEANING

Add the following oils to diffuser:
10 drops of Lemongras Oil
5 drops of Lemon Oil
1 drop of Eucalyptus Oil

UPLIFTING BLENDS:

ORANGE YOU DELIGHTFUL
Add the following oils to diffuser:
10 drops of Orange Oil
25 drops of Vanilla Oil

ESSENTIAL OIL RECIPES

PURIFYING BLENDS

Add the following oils to diffuser:
1 drop of Tea Tree Oil
1 drop of Grapefruit Oil
10 drops of Lemon Oil

ENERGIZING

Add the following oils to diffuser:
1 drop of Peppermint Oil
1 drop of Rosemary Oil
2 drops of Cinnamon Leaf Oil

ROMANCE BLENDS:

LOVE IS IN THE AIR
Add the following oils to diffuser:
1 drop of Patchouli Oil
3 drops of Jasmine Absolute Oil
5 drops of Geranium Oil

CALMING NIGHT

Add the following oils to diffuser:
4 drops of Cypress Oil
4 drops of Lavender Oil
4 drops of Marjoram Oil

THINGS ARE JUST ROSEY

Add the following oils to diffuser:
1 drop of Geranium Oil
15 drops of Rose Absolute Oil

RELAXING BLENDS:


PEACE OF MIND
Add the following oils to diffuser:
10 drops of Lavender Oil
6 drops of Chamomile Oil

HOW TO CLEAN

We recommend that you clean your AromaCasa Deluxe Aroma Diffuser every time you change oils. Oils are corrosive and, over time, they build up on the ceramic disc.

To ensure a long life for your diffuser, follow these simple cleaning and maintenance instructions:

- Turn off the unit and disconnect the power plug. Lift off the lid and empty any water remaining into a sink
- Only use clean water at room temperature to fill the water tank
- Rinse the water tank and wipe it dry with a clean cloth every time you use a different type of essential oil



HOW TO CLEAN

- Use a damp cloth to clean the exterior of the unit
- Use a cotton swab or brush and a few drops of rubbing alcohol to clean the ceramic disc
- Keep water from entering the vent
- Do not move once unit has been filled with water
- Do not use detergents, solvents or abrasive agents to clean the diffuser unit
- Disconnect the diffuser unit from power before cleaning
- Use the diffuser unit on a dry and even surface

IMPORTANT

Manufacturer accepts no liability for damage caused by incorrect use of the Ceramic Aroma Diffuser.



| | |
|--|--|
| | 1. Clean the unit when changing to a different oil |
| | 2. Clean the unit by rinsing the water tank and wiping it dry with a clean cloth |
| | 3. Do not use detergents, solvents or abrasive agents to clean the diffuser unit |
| | 4. Shut off and unplug the power before cleaning |
| | 5. Use the original adapter provided by the manufacturer |
| | 6. If you don't use the device for a long time, unplug and pour water out |
| | 7. Never use hot water or very cold water. Never use corrosive solvents to clean product |
| | 8. Never touch water level sensor and avoid product hitting other objects |

IMPORTANT

| | |
|--|--|
| | 9. Never put your hand above the ceramic disc when product is working, as this could cause pain and damage the unit |
| | 10. Never wrap the adapter with a cloth or paper, otherwise, it cannot dissipate heat normally and may cause deformation and burn the membrane from a short circuit. Never touch the adapter with wet hands. |
| | 11. Do not use other liquids except for water & drops of essential oil or fragrance. |
| | 12. Do not aim the mist at walls, ceilings, or furniture as excess moisture could cause water damage. |
| | 13. Do not take this unit apart, exposing electrical components. Contact customer service for assistance and warranty information. |
| | 14. Never place on loose fabric that can block air flow and prevent the unit from misting and ventilating properly. |

SCENT BETTER
www.scentbetter.com

