

For longer use Re-tighten bolts every 6 months by using the enclosed allen-key. *Using an electric drill can damage the chair. Please re-tighten bolts manually.

Cautions





DO NOT use the chair unless all bolts, screws and knobs are tight



DO NOT use the chair if only components are missing or damaged



DO NOT stand on the chair use as a step stool or ladder



Regularly check all bolts, screws, and knobs are tight



Be careful, some of the part Failure to follow these warnings are **heavy** and has **sharped edge** may cause **serious injury**



If there are any problems, do not hesitate to e-mail us. 🖂 support@neochair.com

Enjoy your new favorite chair

Our goal is to create a perfect customer experience.

Let us know if you have any feedback.

Your comment motivates us to become a better team.



™ support@neochair.com






(i) neochair_office

PAC-E


ASSEMBLY INSTRUCTION

Contents


- Instructions
- User Manual
- Cautions




3 www.neochair.com














·Instructions

















· Instructions














Once all of the armrests bolts are in place, fully tighten each bolt into place.







· User Manual

