




How to Remove a Chair's Gas Cylinder




Push the lever up and check if the gas lift is fully extended.




Flip your chair upside down, and hit the end of the gas lift with a rubber mallet.



Tightly fix the wrench on the thin part of the gas lift.



Twist back and forth until the gas lift is released.



Separate the gas lift from the base.



Please reach out to us if there is any problem
support@neochair.com