


EUR — KITCHEN

PORTABLE INDUCTION COOKTOP

Cooking Temperature Guide



WATTAGE

Low = 200W

Medium = 1000W

High = 1800W

Disclaimer: Cooking Temperature Guide is for reference purposes only. Please ensure food is cooked appropriately before consuming.