

I N S T E O N<sup>®</sup>




**Insteon Hub**  
Quick Start Guide

# Insteon Hub

Status LED     Linking/Idle  
 Unlinking



Ethernet Port



Factory Reset

Power




Ethernet  
Cable



Power  
Cable


## Installation

Connect your Hub to the internet and a power outlet using the cables provided. Avoid switched outlets or power strips.



## Download the App


From your mobile device, download and install **Insteon for Hub** from your device's app store.



Don't feel like searching? Scan the QR Code and tap your store.

## Create an Account


Launch the App and follow the on-screen instructions to create an account and setup the Insteon Hub.



You're done setting up your Insteon Hub; now start adding devices.


## Adding Devices

You can add devices by tapping Add a Device found in the drawer. Follow the on-screen instructions to add light switches, sensors, cameras and more.



## Create a Scene

Control a single light or a group of devices simultaneously. Visit Scenes and then tap Add.



## Trigger a Scene

Sensors can activate scenes. To setup a trigger, simply add a sensor to a scene.




Insteon Motion, Open/Close, Door and Leak Sensors sold separately.



## Create a Schedule

Assign a schedule to individual devices or scenes. Go to the device or scene properties and tap Schedule.



## Configure Alerts

Receive an email alert or push notification when a sensor or device is activated.

Enable alerts by visiting the device properties and tapping Alerts.



## Remote Access

Hub 2 automatically configures itself for remote access so you can control and monitor your home from anywhere in the world.



## Learn More

For the complete Owner's Manual, video tutorials, product support and more, visit:  
**[insteon.com/support](http://insteon.com/support)**

