


# LOFTEK

## LOFTEK

### Remote Control for Timed White Flood light



1. Clear the memory of settled mode. Restart the white light without a fixed time.
2. White light with blending effect.
3. Time Setting of Lighting: Choose 3h/6h/9h/12h, and press Enter, the light will flash twice and start timing, then it will automatically off in 3h/6h/9h/12h.
4. If you want to cancel the time setting mode, please press the Exit button.
5. [ON]/[OFF] Button to switch the unit on and off.