




FAUSTO
Coffee grinder

Spare parts catalogue

Ed. 05.2017



Pos.	#	Description
1	R8G9905931	Upper grind burr support
2	R8G0995950	Grind burrs 65 mm (couple)
3	R8G9995949	Label for setting wheel
4	R0G9905930	Chromed setting wheel
5	R8G9995948	Graduated label for grind setting wheel
6	R8G9905919	Sliding ring for setting wheel
7	R8G9905921	Blocking nut
9	R8G9905920	Lower grind burr support
10	R8G9905923	Anti-vibration support
11	R8G5995934	Motor head
12	R1G9995946	Motor V. 220
13	R1G9995947	MotorV. 110
14	R8G1995941	Tie rod spring
15	R3G1995945	Nut M6
16	R3G1995943	Spring pin
18	R8G3995940	Bean container (compl.)
19	R8G3995939	Bean container cover
20	R8G9905927	Bean container closing lid
26	R1G9905924	Control panel assembly 230V
27	R1G9905952	Control panel assembly 110V
28	R8G4995938	Bean container gasket
29	R1G9905915	Blue on/off switch
31	R8G1995936	Ground coffee hopper
32	R8G1995937	Plastified support fork
33	R8G3995942	Fixing clamp for condensator
34	R1G9905916	Condensator 10MF 230V
35	R1G9905917	Condensator 6MF 240V
36	R1G9905918	Condensator 20MF 110V
37	R0G9905922	Foot (4 pieces)
38	R1G9905913	Power cord UL/CSA
39	R1G9905912	Power cord CE
40	R1G9905914	Power cord AUS/NZ
41	R0G5B95928	Black cover
42	R0G5775929	Chromed cover
43	A619905844	Stainless steel plate