



LM




Remove the key turning counterclockwise.

LM



Insert the key in the hole of the mechanism and turn upwards to expand the iron band.

LM



Turn downwards to tighten the iron band

LM

The cutting board is made from a cedar trunk section, debarked and cut into slices. Even if the timber is naturally seasoned in the open air for more than one year, wood continues his natural expansion and contraction process based on the changing humidity and temperature. The iron band in the middle contains the solid timber; moreover it is adjustable according to temperature and humidity to follow the natural movement of wood, which shrinks or expands accordingly. The presence of small cracks does not represent a defect but it is a natural characteristic of wood, signs of a living material and in continuous change.