



LM




To remove, slide off the razor cover.

LM




To replace, push the razor cover.

LM



To remove the blades, push the botton.

LM



To replace the new blades push until you hear a click.