

0

ໍ່ໍ

INSTALLATION INSTRUCTIONS

For Seaview Modular Pole Top: MODTOPPTM1

Refer to website for most up to date instructions and videos.

WWW.SEAVIEWGLOBAL.COM



TOOLS NEEDED



Sudbury Elastomeric Marine Sealant is recommended. To purchase call 800-655-7922 or visit www.seaviewglobal.com



Before beginning please make sure that the Seaview Top Plate will face forward. If you are not using a light bar then insert the plastic plug into the back of the modular top. Make sure that the plug snaps in place from the light bar pin.

If you are using a light bar, do not use the black light bar pin.



2

Apply marine adhesive sealant to the inside of the modular top where the pole will slide into. Be sure to get around the bolt holes.

TIP:

Dry fit the modular pole top over the pole. Some will feel a bit loose (approx 1/16" of space). This occasionally happens with the combination of tolerances between the pole and the pole top. You can use a clear silicone and spread a thin layer around the inside of the pole top and let it dry. This should help fill in the gap and tighten better.



3

Slide the modular top assembly onto the top of the pole making sure that the bolt holes line up.





Place the rubber gasket into the groove on the top of the modular top and then place the Seaview Top Plate ontop.

Make sure that the eight bolt holes line up with the eight bolt holes on the modular top.



6

Insert the rubber cable grommet into the top of the Seaview Top Plate.



Secure the Seaview Top Plate to the modular top using the eight bolts included in your Seaview Top Plate kit.





Apply marine adhesive sealant around the base of the modular top.



THIS PAGE IS INTENTIONALLY LEFT PLANK.

THIS PAGE IS INTENTIONALLY LEFT PLANK.

SEAVIEV// ELEVATE YOUR ELECTRONICS



Tel: 800-655-7922 www.seaviewglobal.com

EUROPEAN OFFICE

Tel: +33 4 94 53 27 70 www.seaviewprogress.com 2-073119