



Compressed Air Advisors, Inc.

Phone: 877.247.2381

info@compressedairadvisors.com www.compressedairadvisors.com

## **Installation of Micro**

Check for damage that may have occurred during shipping DO NOT OVER TIGHTEN FITTINGS, AVOID DAMAGE TO COUPLINGS

- 1. Mount the MICRO mounting bracket on a wall or secure surface. Make sure it is secure.
- 2. Remove the yellow plastic plug from the cartridge.



- Insert cartridge into the MICRO mount.
   Hand tighten cartridge counter-clockwise.
   Label should be facing you when fully in place.
- 4. Connect condensate lines to decompression chamber using 1/4" polyethylene tubing.

  Condensate flows out through the cartridge.
- 5. Install a 1/4" polyethylene tubing into the outlet of the MICRO. Ensure that there are no kinks.
- 6. Check for leaks

Replacement Filters: F10106

Installation Kit: F10101

## **ATTENTION**

Monitor water being discharged from unit.
When water turns cloudy or maximum lifespan is reached, replace unit!

~	77		_	_		G
A V		м	IV.		м.	

## MAY 175DSI

\*Decompression chamber must be used.
MAX 125PSI without decompression chamber

	MICRO		
HP	Months		
5	18		
7.5	18		
10	12		
15	12		
20	6		
25	6		

LEAN RESOURCE

Install Date	

**Change Out Date**