



LETATWIN IS A PORTABLE PRINTER DESIGNED FOR CONTROL PANEL

INTEGRATED RECHARGEABLE BATTERY *LM-550A2B ONLY

Even when you can not find a power supply nearby, you can continue wire numbering and device labeling on site by loading AA size rechargeable batteries x 4pcs.

*Panasonic eneloop AA rechargeable batteries are recommended. Please inquire about other rechargeable battery brands. *Rechargeable batteries are not included with a printer purchase. *You can print & half-cut approximately 10m(20mm pitch length X 500 block)tube using fully charged rechargeable Ni-MH batteries. *Electrical power source will NOT automatically change from AC supply into integrated batteries when power failure occurs.



*`eneloop` is a registered trademark of Panasonic Corporation group.

Printing

2 Bringing Printer





3 Printing without Power connection.





2 EXTENDED BLOCK LENGTH


Extending half cut function block length can provide higher character visibility.

Printer	Maximum Length of marked block			
Model	PVC TUBE	HEAT SHRINK	TAPE	ID PLATE
LM-390A	10-60mm	10-60mm	4-60mm	NA
LM-550A	10-60mm	10-60mm	4-60mm	4-60mm
<u>LM-550A2</u>	10- <u>150</u> mm	10- <u>150</u> mm	<u>3.5</u> -60mm	4-60mm

1 Half Cut function



Half cut tubing is easily cut by hand.





Depth of the half cut can be adjusted.

2 Available block length

Vinyl(PVC) Round Tube: 10-150mm/block



Heat Shrink Tube: 10-150mm/block



Tape: 3.5-60mm/block


	TB01	PLC-01	THERMOSTT	COMVERTER+24V: 01
_				

MARKING SOLUTIONS WITH THE UNIQUE FEATURES BELOW.

SEQUENCE SETTING EXTENDED TO 3 TIMES IN A BLOCK

One sequence in a block:


X04




X05

X06

Two sequences in a block;



Three sequences in a block;



Lau		
		_
2	A02/002	

image

X01/G01-01	X02/G02-02	X03/G03-03
	Salara Salara	

X03

INPUT ASSISTANCE FUNCTION

image

A01/G01

If the amount of input characters for wire numbering is large, it can feel frustrating. You can use this function to cut your input data time.

1. When printing wire numbering as below:

TARGET	
PS+EE01+FC(+24V) 1 : 1 : L01	
PS+6502+08 (+24V) 02 (107/25+6501+50(+24V) 1/1/1/101	

2. Input your numbers and characters with keyboard according to the source and target and then press the 'block' key.



By pressing `SHIFT` and `A/a`keys together, you can recall the characters entered immediately before. Press `ENTER` if you want to print it.






- *This function is available only when one slash [/] is entered between the source and target.
- *You can also select input candidates with the ▲ / ▼ keys.
- *`Sequence Settings` are not automatically copied by this function.

AUTOMATIC 180 DEGREE ROTATION

1.Input Data:



2. Print Setting:



3. Printed block:



- *Marking blocks are automatically duplicated, the duplicated marking blocks can not seen if you press `IMAGE` key.
- *If the REPEAT` number is set to 2, please change the `REPEAT` setting into 1.
- *`INPUT ASSISTANCE FUNCTION` is not suitable for the 180 degree rotation function.

6

MORE CHOICES IN `AUTO SIZE`


1. STANDARD AUTO CHARACTER:

You can shorten the character block length but character height also changes.



2. FIXED HEIGHT AUTO CHARACTER:


Only character height is fixed, character length changes automatically for higher visibility.



*New for the 550A2 series

3. SUPER AUTO CHARACTER:

You can shorten character size&space/ line space, so you can save consumable consumption.



*New for the 550A2 series

4. Printing block length is automatically fixed by setting character size.



7

MORE CHOICES IN `CHARACTER FONT`

1. STANDARD: Same in past models.

0123456789

ABCDEFGHIJKLM

NOPQRSTUVWXYZ

-03/TBD0-03 TBAI-04/TBD

2. CLEAR CHARACTER:
Desinged for decreasing misreading.

0123456789

ABCDEFGHIJKLM

NOPQRSTUVWXYZ

-02/TBD0-02 | TBAI-03/TBD

*Especially`3``6``8``9``0(zero)``O(oh)` are designed for prevention from misreading.

3. SQUARE SHAPE: Height & Width are equal length.

0123456789

ABCDEFGH I JKLM

NOPORSTUVWXYZ

02/TB00-02 TBAI-03/TB

*Actual character size is little bit smaller than the set characer size.

8

UPGRADED FEATURES FOR THE LM-550A2 SERIES

Printer	Upgraded Functions			
Model	Maximum Print Length	Maximum Repeat blocks	Maximum Print Blocks	Maximum Pitch Length Setting
LM-390A/550A	20m/file	100 times	300 blocks/file	5 types/file
<u>LM-550A2</u>	<u>100m</u> /file	<u>300</u> times	999 blocks/file	999 types/file

Printer	Character Height in Auto-size mode			
Model	TUBΕφ2.5-2.9mm		TUBEφ3.2-3.6mm	
LM-390A/550A	2.0mm	COM05	3.0mm	COMOS
<u>LM-550A2</u>	<u>3.0</u> mm (150%UP)	COM05	<u>4.0</u> mm (133%UP)	COMOS

Ink Ribbon Window



^{*}New for the 550A2 series

^{*}New for the 550A2 series

USEFUL FUNCTIONS

1 VERSATIL SEQUENCE SETTING

START / END



1010, 1011, 1012 ... 1025

ODD / EVEN



ODD: 1, 3, 5, 7, 9, 11.... EVEN: 2, 4, 6, 8, 10, 12....

8/10/16 SCALE



8 Scale: 1,2,3.. 7, 10, 11.. 10 Scale: 1,2,3.. 9, 10, 11.. 16 Scale: 1,2,3.. 9, A, B ..

ALPHABETICAL



CAP: A, B, C, D ... Z L.C.: a, b, c, d, z

2 ELECTRICAL SYMBOLS

`Electrical` and
`Unit` symbols are
available in printer
for device labeling.





3 PREVIEW

You can check total print length & content by pressing `IMAGE` key.






*`Preview` is available for LETATWIN PC EDITOR (for 550A2 series).

4 UNDERLINE & FRAME

in `REPEAT` key on keyboard.




image



in `FRAME` key on keyboard.



image




*`UNDERLINE` is available for the LM-550A2 series.

5 DOT (PERIOD) AT END

You can add a dot (period)at the end of each blocks by setting `PERIOD` in `ADVANCED SETTINGS`






*`DOT(PERIOD) AT END` is available for the LM-550A2 series.

6 WORD REGISTRATION

Frequently used words can be registered in the internal memory (up to 30 words). This function is good use for panel device labeling.



7 COPY & PASTE

You can improve data input process by using this COPY & PASTE function. This function is especially effective when inputting large data sets.



BASIC FUNCTIONS

11 INK RIBBON Thermal transfer for Vinyl(PVC) & HS tube etc.



Remove



Insert



- *Black ink ribbon is 110m(120.3yard)/roll, white ink ribbon is 70m(76.6yard)/roll
- *Expression of `Halogen Free` is accordance with IEC 61249-2-21, Chlorine(CI) \leq 0.09wt%(900ppm), Bromine(Br) \leq 0.09wt%(900ppm), total content rate of both materials is \leq 0.15wt%(1500ppm).

2 VERSATILE PRINT MEDIA

L' TUBE

(PVC/Drum Roll/No UL)



'N' TURE

(PVC/UL224/E171616/ 105℃/600V)



POLYESTER TAPE

(w5/9/12mm/white/yellow/transparent)



ID PLATE

(w4.1xt1.0mm,white)



3 PC CONNECTION











- *`Windows`and `Excel` are registered trademarks of Microsoft Corporation of North America and other countries.
- *LETATWIN PC EDITOR can be downloaded from the MAX CO LTD international website .

4 BASIC SPECIFICATION

Printer	Upgraded Functions			
Model	Print Speed	20mm + Half-cut Performance	Black Ink Ribbon Length	Internal Memory Characters
LM-380EZ	25mm/sec	35 blocks/min	50m/roll	up to 61,250pcs
LM-550E	27.5mm/sec	37 blocks/min	110m/roll	up to 61,250pcs
LM-390A	35mm/sec	50 blocks/min	50m/roll	up to 100,000pcs
LM-550A	40mm/sec	52 blocks/min	110m/roll	up to 250,000pcs
LM-550A2	40mm/sec	52 blocks/min	110m/roll	up to 250,000pcs

- *`Print Speed` is under the standard speed mode.
- *`20mm + Half Cut Performance` indicates how many blocks with
- 20mm pitch can be printed and half-cut per a minute.
- *`Black Ink Ribbon Length` refers to the ink ribbon length of LM-IR50B and 300B.
- *`Internal Memory Characters` is maximum number of 50 files can be saved in each model.

5 HARD CARRY CASE NUMERIC KEY

ADVANCED SETTINGS

`ADVANCED SETTINGS` can help you make more specific settings for your marking jobs and you can improve processes for better performances.




Press `OPTION` key to select this function.

TRECT PRINTING PC ATA FILE TRANSFER UBE HEATER


1 6,9 MARKINGS

To identify clearly, you can select normal/underbar /dot to 6 and 9 digits.




2 DEFAULT VALUE SETTINGS


You can set default values for `PITCH LENGTH` & `REPEAT` to values which you often use to set the printer.



3 PRINT POSITION LINE

You can adjust up and down. (-10∼+12)





4 HALF CUT POSITION ADJUSTMENT

You can adjust the half cut position by setting the right side margin length. (-2.0 ~+2.0mm)






*`+` Increases right margin , `-` Decreases right margin .


5 PRINT DENSITY

You can choose 8 settings for print density.



6 PREFERABLE PRINT SETTING

You are able to save up to 6 setting values for PRINTING DENSITY/ POSITION OF PRINTING LINE/ CUTTING POSITION.



*In addition to the above functions, you can also set LOW TEMPERATURE MODE/AUTO POWER-OFF/ JUSTIFICATION(LEFT/CENTER/RIGHT FOR NORMAL PRINT MODE and PRINT STYLE OF REPEAT & SEQUENCE.