

Ijuin-Rod

Recommend Guide Spacing

Yomogi Series

Model Name		Guide	Length	Section	etc
7'06" 4wt Standard	10	Stripping	25 15/16"	Butt	Size #10
	9	snake 3	4 5/8"	Middle	
	8	snake 2	12 9/16"	Middle	
	7	snake 1	20 7/16"	Middle	
	6	snake 1	28 5/16"	Middle	
	5	snake 1	6"	Tip	Important guide
	4	snake 1/0	12 5/16"	Tip	
	3	snake 1/0	17 13/16"	Tip	
	2	snake 2/0	22 9/16"	Tip	
	1	snake 2/0	27 5/16"	Tip	
	0	Top	#4.5		

\* The value is length from the end of own section.

Caution>

Alignment of Guide Spacing

- 1 Put the guide on this blank temporarily using scotch tape at the value point.
- 2 Connect all sections.
- 3 Grip the position of grip space.
- 4 You keep the rod horizontally.
- 5 Shake the blank up and down.
- 6 You can see the point that was not moved in the tip section.
- 7 This is the point of 5th guide.
- 8 If the 5th guide point was different from the point that I wrote down before, please dislocate the 5th guide to the point that not move point.  
The 5th guide position is very important. If the guide put on difference position, line can not go through the guide.  
And please put the guide adding same error range of 6th guide from the 6th guide til the stripping guide.

Ijuin-Rod

393-1 Kareigawa Hayato Kirishima-City Kagoshima Japan Zip 8995113

Kazutomo Ijuin

Web

<http://www.ijuin-rod.com>

eMail

[mail@ijuin-rod.com](mailto:mail@ijuin-rod.com)