TricketTM Instructions

SIMPLY WASH AND DRY BLINDS IN PLACE

CLEANING VERTICAL BLINDS

With the washer sleeves, start at the top of the blind and move down. Release pressure when moving up to avoid taking the blind off.

CLEANING LOUVERED WINDOWS

Scrub with the washer sleeves thoroughly until dirt is dissolved. With the squeegee blades, start from the right side and move in one continuous stroke to the other side. Maintain only moderate pressure throughout. Repeat with the squeegee if necessary. Re-wet each time.

ADJUSTING FOR THICKNESS OF GLASS

- 1. Loosen the wingnut
- 2. Place squeegee blades on each side of surface to be cleaned.
- 3. Grasp the squeegee blades between the thumb and forefinger and press together with moderate pressure.
- 4. Tighten the wingnut. Your Tricket™ is now properly adjusted.





SORBO PRODUCTS INC PALM DESERT CA www.sorboproducts.com

Tricket™ Instructions

VERTICAL BLIND AND LOUVERED WINDOW CLEANER

SIMPLY WASH AND DRY BLINDS IN PLACE

CLEANING VERTICAL BLINDS

With the washer sleeves, start at the top of the blind and move down. Release pressure when moving up to avoid taking the blind off.

CLEANING LOUVERED WINDOWS

Scrub with the washer sleeves thoroughly until dirt is dissolved. With the squeegee blades, start from the right side and move in one continuous stroke to the other side. Maintain only moderate pressure throughout. Repeat with the squeegee if necessary. Re-wet each time.

ADJUSTING FOR THICKNESS OF GLASS

- 1. Loosen the wingnut
- 2. Place squeegee blades on each side of surface to be cleaned.
- 3. Grasp the squeegee blades between the thumb and forefinger and press together with moderate pressure.
- 4. Tighten the wingnut. Your Tricket™ is now properly adjusted.



