

The first steps:

If you would like to establish a *Bluetooth* connection for the first time, you must activate the *Bluetooth* function in your mobile telephone and start the search for *Bluetooth* devices. Search for a device with the description „CC 9068“. If several devices have been found, please select and connect the CC 9068 and enter the **PIN number `1234`**. The subsequent functions are described in the operating manual.



Voice commands which are valid for all menus:

Cancel

Ends the voice control function.

Help / What can I say

By saying Help you can hear the commands, which are available in each submenu.

Back

One step back.

Head menu

The main menu is open.

The most important voice commands:

Head menu

Dial Joe Bloggs

Will not be displayed in the head menu. Direct call of a phonebook entry.

If you have saved more than one number for one person, you can dial directly via the category, e.g.

„Dial Joe Bloggs home“

It is important to match the announced name exactly with the phone book entry.

Dial number

- Digits (0..9)
- Playback
- Delete all
- Delete last
- Dial
- Delete group

Special symbols like +, * and # can be actuated in the same way as the Pause function (space character) e. g. for mailbox functions.

Phone book

- Select entry <digit>
- Playback
- Play list
- Select Joe Bloggs
- Dial
- Dial search
- Get details
 - Dial home
 - Dial mobile
 - Dial office
 - Dial general
 - Dial sim
 - Voicetag
 - Store
 - Number
- Next
- Previous
- Next Page
- Previous Page

Redial

Here, you can re-dial the telephone number which was most recently dialled with the hands-free car kit.

Call lists

- Dialed calls
- Received calls
- Missed calls

In these menu items the following commands are available to you:

- Select entry <digit>
- Number
- Playback
- Dial
- Next
- Previous
- Next page
- Previous page

Music

If a mobile phone is connected with the hands-free car kit in the A2DP mode, you are able to start the playback of music using this command.

Messages

Read new message Read new emails

- All messages
- New messages
- All emails
- New emails

Will not be displayed in the head menu. With this voice prompt you can directly reach a new message.

- Bluetooth
- Phones
- Music devices
- A2DP active

- Voice dial
- Magic word
- Advanced help on/off
- Audio feedback on/off
- Speaker adaptation
- Description

- Audio
- Ringtones
- Volume
- Mute delay
- External audio on/off
- Balance
- Installation

- Display
- Sleep mode
- Illumination
- Day/Night mode
- Colour theme
- Calibration
- Rotation

- Device
- Call answering
- Language
- Phone book options
- System
- On-call duty

CC 9068

In these menu items the following commands are available to you:

- Select entry <digit>
- Playback
- Dial
- Read
- Next
- Previous
- Next page
- Previous page

Settings



Memo

A voice memo can be saved directly from the main menu or during a telephone call.

Switch phones




This command is only available as the Multipoint function has been activated. Via this command you are able to swap the priorities of the mobile telephones.

Activate voice dial

If the Magic Word function is activated, you can start the voice control by this command.



Handling via touch screen:

All displayed commands can also be operated intuitively via touch screen and are self explaining. Except the commands **Read new message**, **Read new emails** and **Dial Joe Bloggs**. The operation can be carried out via possibly existing arrow keys. With the red symbols   you can cancel an action or go a step back. With the green symbol  you can confirm actions.