



# Younix Programmable Timer Set Instructions & Guidelines

## IMPORTANT

Read this before using the  
Younix Programmable Timer Set

### Before using the Programmable Timer Set

- > Check the product for any manufacturing defects prior to use. If defects are evident, do not use the product and contact Younix immediately.
- > Check if you get: a timer, a remote control and an AC adapter
- > Check if all programs work properly by following the technical instructions. If all or some of the programs don't work as shown in the technical instructions, do not use the product and contact Younix immediately.

### Product care

- > Keep the Programmable Timer Set stored in a clean and dry environment.
- > Keep Programmable Timer Set out of direct sunlight for prolonged periods.
- > Respect power Input AC100-230V / Output: 12V
- > Never open or try to repair the timer

### 2 Years Warranty

- > Younix will warranty this product from defects in material, functionality and workmanship for 2 years
- > The warranty applies only to the original purchaser of the product for so long as the original purchaser owns the product, and is non-transferable
- > Warranty does not cover any Programmable Timer Set which has been damaged due to negligent or faulty use, alteration, maintenance, storage or handling by the use.
- > This warranty does not include normal wear and tear.
- > Younix' warranty does not cover accidental falls

### Younix® No BS Policy

- > We take our products and services seriously. It's for this reason we offer a hassle-free No BS policy with all our products. If there's ever an issue with our service or product that is outside of normal wear and tear (see our Terms & Conditions), simply let us know and we'll take care of it with a No BS attitude.