


BEACON LANTERN

User Guide

BAREBONES

PRODUCT COMPONENTS



QUICK USE

Install battery before use.

1. Grasp Metal Hood **C** in one hand and Lens **F** in the other. Firmly twist lens base counter-clockwise to separate.
2. Twist Battery Housing **G** counter-clockwise to remove.
3. Insert Li-ion Battery **H** into housing with symbol **+** and exposed copper end towards the top of housing.
4. Reassemble Battery Housing **G**.
5. Lens **F** will only engage in correct position when flat spot on lens aligns with USB-A Charging Cable **E** plug under Metal Hood **F**. Twist clockwise to lock.

Note: *Follow steps 1-5 for battery replacement.*

**DO NOT REMOVE
PLASTIC WRAP ON BATTERY**

OPERATING INSTRUCTIONS

POWER & BRIGHTNESS

Use Power/Dimmer Switch **B** to power lantern on, off, and to adjust brightness levels.

Power On: Clockwise from off position.

Brightness: Adjust by turning dimmer switch clockwise to increase brightness and counter-clockwise to decrease brightness.

Power Off: Counter-clockwise until click.

CHARGING

USB-A Charging Cable **E** is nested under Metal Hood **F**.

Flip lantern upside down to locate cable.

Pull cable down and plug into external charging source.

Note: 30" Extension Cable **I** included.

When fully charged, all three Battery Life Indicator **D** lights will be solid.

Replace USB-A Charging Cable **E** under Metal Hood **F** when not in use.

FAQ

HOW OFTEN SHOULD I RECHARGE THE LANTERN?

To prolong the life of the Lithium-ion battery, it's important to keep your lantern charged. The battery needs to be charged every three months, even if not in regular use.

WHY IS THE BATTERY LIFE INDICATOR BLINKING?

The Battery Life Indicator **D** will begin blinking when it's time to charge the lantern.

WILL I NEED TO REPLACE THE LED?

The Beacon Lantern was designed to not require LED replacement. It comes with a one year warranty and is rated for 20,000 hours of use.

WARNING


The Beacon is a high intensity lighting device.

Avoid shining the light directly into eyes.

This product is not intended for use by children.

Do not disassemble the upper LED housing of your lantern. Doing so may damage the lantern and will void the warranty.

SPECIFICATIONS



LED	6 LEDs: 3 WATT CREE
LUMENS	LOW: 30 HIGH: 220
TEMPERATURE	3000K
VOLTAGE	3.6V DC
BATTERY	LI-ION 18650 2200mAh 3.7V 8.14Wh
RUN TIME	LOW: 200+ HRS HIGH: 3 HRS
RECHARGE TIME	4-5 HRS
INPUT	5V USB-A, UP TO 1A MAX
DIMENSIONS	3.75" x 3.75" x 5" (7" w/ CARABINER)



RoHS



BAREBONES

Customer Service
1-855-895-7040

Email
info@barebonesliving.com

120621

Scan the QR code to view this information online.



BAREBONESLIVING.COM/INSTRUCTIONS