

# WOODEN CAMERA<sup>®</sup>

## EASY RISER (RED DSMC2)

### INSTALLATION GUIDE



© Wooden Camera, Inc. 2011-2019

## INSTALLATION

2x 3/8-16 captured screw

1. Locate and align the two 3/8-16 Holes on bottom of Camera and Easy Riser Top.

2. Select 3/8-16 Screws, tighten Easy Riser to Camera with screwdriver.

