

# WOODEN CAMERA®

## SIDE PLATE (URSA)

### INSTALLATION GUIDE



© Wooden Camera, Inc. 2011-2019

## INSTALLATION

3x M3 Socket cap

1. Locate and remove the top three screws above the LCD screen.

2. Select Side Plate, align M3 Holes over LCD screen, select and tighten M3 Screws with allen wrench.

