


C-BOX (CONVERTER, V-MOUNT, GOLD MOUNT)


Included:

(1) Mini USB



V-MOUNT INSTALLATION


1. For proper use, a V-Mount plate must be wired or connected to the camera directly. Quick Back and WC V-Mount (Epic/Scarlet) shown below for reference.
2. **SELECT C-BOX**, align and attach **SIDE B** to **CAMERA V-MOUNT**.
3. Select **BATTERY**, align and attach to **C-BOX V-MOUNT**.
4. Power will pass from **BATTERY** to **C-BOX** and into **CAMERA V-MOUNT**.
5. 5V power is available via Mini USB for wireless transmitter.



BATTERIES may vary in appearance

GOLD MOUNT INSTALLATION

1. For proper use, a Gold Mount plate must be wired or connected to the camera directly. Quick Back and WC Gold Mount (Epic/Scarlet) shown below for reference.
2. **SELECT C-BOX**, align and attach **SIDE B** to **CAMERA GOLD MOUNT**.
3. Select **BATTERY**, align and attach to **C-BOX GOLD MOUNT**.
4. Power will pass from **BATTERY** to **C-BOX** and into **CAMERA GOLD MOUNT**.
5. 5V power is available via Mini USB for wireless transmitter.



BATTERIES may vary in appearance