

WOODEN CAMERA®

PUSH BUTTON ARRI ROSETTES

INSTALLATION GUIDE

1. Install Push Button Rosette using 5mm allen wrench.



2. Install ARRI standard rosette handle.



3. Adjust rotation tension using 5mm allen wrench as desired.

